



IMPORTANT!




READ THIS MANUAL BEFORE OPERATING MACHINE.

COMPACT TRACTOR LOADER BACKHOE

PARTS MANUAL

TERRAMITE CORPORATION

SINCE 1965



79



MADE IN THE USA



"Backed by a World of Experience"

600 Goff Mountain Road • P.O. Box 7146, Charleston, WV 25356-7146 USA
1.800.428.3772 Fax 1.800.776.4845 • International 1.304.776.4231 Fax 1.304.776.4845

www.terramite.com

Revised 10/2006



Safety

Safety is a prime consideration in the design of this machine. Guards, shields and other safety features are built in wherever possible. However, accident reports show carelessness causes the majority of accidents. You can avoid most accidents by observing the safety rules on these pages. Study these rules carefully and enforce them on the job:

 Never allow minors to operate or be in the vicinity of the machine while working.

 Do not allow the T5C to be operated by anyone who is intoxicated or on medication that would affect their judgement or ability to operate the machine.

 The machine is designed to be operated by adults who are of average size and weight. Persons who are extremely heavy, big or tall, or those who are exceedingly short, light or weak can not run the machine.

Before Operating the Terramite T5C

 Read the Operator's Handbook. Never allow anyone to operate the backhoe without reading the Operator's Manual and Safety Instructions. This should be followed by supervised training.

 Check Your Equipment. Always make a complete inspection of the machine before operating it that day. Check the hydraulic system and the engine oil level. Then check the machine for broken, missing or defective parts. Check the tires for cuts, bulges, irregularities and abnormal wear and proper inflation. Check the neutral position of the foot pedal. A malfunctioning machine invites accidents.

 "Do Not Operate" Tag. When you service the machine, put a "**DO NOT OPERATE**" Tag on the instrument panel. This tag (Terramite Part Number 1-400.82) is included with each machine.

 Keep Your Machine Clean. Slippery surfaces are hazardous. Remove oil, grease or mud from the operating area of the tractor. Failure to keep these areas clean could cause a serious accident.

 Wear What is Needed for Protection. Protect yourself by wearing all the protective clothing and personal safety devices issued to you or required by job conditions. You may need a hard hat, safety shoes, safety glasses, heavy gloves, hearing protection, reflective clothing, wet weather gear and a respirator. Never take chances by wearing loose clothing, watches or rings.

 Look For Hazards. Walk around a new work area and check for any hidden hazards, such as holes and abutments.

 Read and Heed Safety Decals. Make sure the safety and information decals can be easily read. To clean decals, use soap and water only. Gasoline or solvents will destroy the decals. If these decals are missing or illegible, call our Parts/Service Department for replacements.

 Roll-Over Protective Structure. All Terramite T5C tractor loader backhoes are equipped with a Roll-Over Protective Structure. This is designed to protect the operator in the event of a roll-over. If this machine has been rolled over, the R.O.P.S. must be replaced. It is designed to be used only once.

 Driving Pivot Pins. When driving pivot pins in or out, use care to guard against injury from particles that may chip off the pin or object used in striking the pin. These pins can fly out at high speed if they are not tapped lightly just before they come out. Make sure there isn't anyone or anything in the way, in case the pin flies out. Safety glasses should be worn.



See Operator's Manual For More Safety Information





Before Your Start

⚠ READ OPERATOR'S HANDBOOK ⚠

*Carefully read all **WARNING!** and **DANGER!** messages in handbook
and be sure you understand their meanings.*

IMPORTANT! If this machine is used by the owner, an employee, or is loaned or rented, make sure that the following instructions are complied with:

- 1. The operator has read the Operation and the Safety Rules sections of the Operator's Handbook.**
- 2. He has been instructed on the safe and correct use of the machine.**
- 3. He has practiced operating the machine and the use of all controls in a safe, clear area before he operates the machine on a job site.**
- 4. He has read all safety decals on the machine.**
- 5. He has been informed to clear the area of other persons and hidden hazards before starting the machine.**


Table of Contents

Safety Tips	1.1	T9 4WD Cartridge Block	4.10
Before You Start	1.2	T9 Drive System Distributor Block	4.11
Table of Contents	1.3	T9 Filter Assembly	4.12
Section Two: Parts			
Oil Change and Type Specifications	2.1	T9 Backhoe Valve Assembly	4.13
Front with Loader Arm Assembly Raised	2.2	T9 Hydraulic Oil Tank Assembly	4.14
Left or Right is Determined from the Operator's Position	2.3	SECTION FIVE: COMPONENTS	
View of Front Loader Bucket	2.4	T9 Pin Chart	5.1
View of Right Side of Loader Bucket	2.5	T9 Pin Chart 180 Degree Swing	5.2
View of Underside of Arm Center	2.6	T9 Wiring Diagram - Perkins 103-15	5.3
View of Right Side of Arm Assembly	2.7	Hydrastatic Transmission	5.4
View of Front Axle 2WD	2.8	Hydrastatic Transmission (continued)	5.5
View of Front Axle 2WD (continued)	2.9	Sunstrand Transmission	5.6
View of Front Axle 2WD - Ball Socket Style (Bumper Not Shown)	2.9	Sunstrand Transmission (continued)	5.7
View of Hub Assembly 2WD	2.10	Glow Plug Timer	5.8
Four Wheel Drive Front Axle (Bumper Attached)	2.11	MAB/MAE Torquemotor Exploded Assembly View - Typical	5.9
View of 4WD Front Axle	2.12, 2.13	Gear Pump Part Number 66007	5.10
View of Right Front Tire and Rim	2.14	Drive Motor Part Number 62000 - 4WD Only	5.11
View of Right Side of Tractor &	2.15	Rear Axle Assembly	5.12
View of Right Rear Tire and Rim	2.16	Rear Axle Assembly (Continued)	5.13
View of Left Side of Tractor	2.17	General Tightening Torque for Bolts, Nuts and Taperlock Studs	5.14
View of Battery from the Left Side of Engine Compartment	2.18	Schematic View of Typical Control Valve Assembly	5.15
View of Power Steering Gear	2.19	Parts Ordering Information	5.16
View of Loader Valve Assembly	2.20	4-Way, 3-Position Valve Section	5.17
View of Front Valve Linkage Assembly	2.21	Load Check Plug Assembly	5.18
View of Operator Position Facing Dash	2.22	SPK Monoblock Valve	5.19
View of 2WD Transmission Assembly	2.23	Model J-HP High Pressure Relief	5.20
View of 2WD Sunstrand Transmission Assembly	2.24	Hose and Fitting Location for V10 Valve (180)	5.21
View from Top of Transmission Assembly 4WD	2.25	View from Operators Position for V10 Valve (180)	5.22
View of Cam Roller Center Spring 4WD	2.26	Valve Section Service Kits V10	5.23
View of T9 2WD Transmission Assembly	2.27	Valve Section Service Kits V10 (continued)	5.24
View from Right of Foot Pedal Control	2.28	Valve Section Service Kits V10 (continued)	5.25
View from Right Side of Hydraulic Tank &	2.29	Valve Section Service Kits V10 (continued)	5.26
View from Left Side of Fuel Tank	2.30	Valve Section Service Kits V10 (continued)	5.27
View of Hydraulic Filter Assembly	2.31	Valve Section Service Kits V10 (continued)	5.28
View from Back of Seat	2.32	Rod Assembly	5.29
View of Operator Position at Rear Valve	2.33	Hydraulic Cylinder Diagram	5.30
View of Operator Position of Rear Valve (Continued)	2.34	T9 - Rear Boom Hose Diagram V20	5.31
View from Operator Position of Rear Valve (Continued)	2.35	T9 - Rear Boom Hose Diagram V10	5.32
View from Operator Position of Backhoe Valve (Continued)	2.36	T9 - 2WD Hydraulic Hose Diagram	5.33
View of Operator Position at Rear Valve (180 Swing)	2.37	T9 - 4WD Hydraulic Hose Diagram	5.34
View of Fitting Location for Rear Valve (180 Swing)	2.38	T7/T9 Sunstrand Diesel Hose Diagram with Oil Cooler	5.35
View of Hose Location at Rear Valve (180 Swing)	2.39	Section Six: Options	
View from Front of Rear Axle w/Brake	2.40	Quick Attach Backhoe Buckets	6.1
Top View of Parking Brake Assembly	2.41	View of Clam Shell 4 in 1 Bucket (Factory Installed Option)	6.2
View from Left Side of Outrigger Assembly	2.42	View of Clam Shell 4 in 1 Bucket from Drivers Position (Factory Installed Option)	6.3
View of Left Side of Swing Assembly Non-180 Degrees	2.43	View Under the Dash for Clam Shell 4 in 1 Bucket (Only as Factory Installed Option)	6.4
View of Right Side of 180 Degree Swing Assembly	2.44	SECTION SEVEN: TRANSLATIONS	
View of Left Side of Backhoe Assembly	2.45	Translations	7.1 to 7.6
View of Left Side of 180 Degree Backhoe Assembly &	2.46	SECTION EIGHT: INDEX	
View of Right Side of Rear Bucket & Linkage Assembly	2.47	Index	8.1 to 8.4
View of Left Side of Rear Bucket & Linkage Assembly Tooth Caps	2.48		
Section Three: Decals			
Decal Location - Left Fender	3.1	RECORDS	
Decal Location - Right Fender	3.2	Serial Number _____	
Decal Location - Front Arms	3.3	Model# _____	
Decal Location - Rear Valve	3.4	Engine Type: _____	
Decal Location - Side View	3.5	Engine Serial Number: _____	
Decal Location - Side View (continued)	3.6	Accessories: _____	
Decal Location - Dash	3.7	_____	
Decal Location - Air Filter from Under Hood	3.8	_____	
Section Four: Hydraulics			
T9 Oil Cooler	4.1	_____	
T9 Steering Column 2WD and 4WD	4.2	_____	
T9 Power Steering Cylinder	4.3	_____	
T9 Loader Valve Assembly	4.4	_____	
T9 4WD Front Axle Assembly	4.5	_____	
T9 Torque Motor - 4WD	4.6	_____	
T9 Transmission - 2WD	4.7	_____	
T9 Transmission - 4WD	4.8	_____	
T9 Torque Motor - 2WD	4.9	_____	

Oil Change and Type Specifications

When your machine is new, the hydraulic system oil and filter must be changed within the first 50 hours of use and every 250 thereafter. Refill the hydraulic reservoir with engine oil type API SF.CD 15W40 when outside temperature is above 40 degrees F. Use engine oil type API SF.CD 10 weight when outside temperature is below 40 degrees F. Replace filter with Terramite / 21002 filter. It is important to follow these instructions to alleviate any cold weather engine starting problems and any pressure or heat related component failures.

***DO NOT USE REGULAR HYDRAULIC OIL!
MAJOR DAMAGE WILL RESULT!***



This is the position machine must be in to check proper level in hydraulic tank.

Required Pre-Fuel Filter Changes for Gasoline and Diesel Machines

ALL Terramite Backhoes and Street Sweepers require their pre-fuel filters to be changed at the first 20 hours and again at 40 hours. These pre-fuel filters should be changed every 20 to 50 hours thereafter using a 10 micron filter.

The following Pre-fuel filters are designed for gasoline and diesel engines.

Terramite 15506

NOTE: Filling tank with loader or backhoe in any other position will result in overfilling and spillage of fluid through the breather cap. Replace cap if oil should ever spill out of breather cap since it will clog off the air supply that the systems needs to operate properly.

On Hand Spare Parts

Following is a list of spare parts we recommend you keep on hand.

Oil, Fuel and Air Filters

One of each size Cylinder Packing Kit (specify serial number of machine when ordering)

Grease Fittings

One each of a longest length and medium length Hoses and spare Cylinder Fittings

Tie Rod End

Pedal Return Spring

Wheel Bearings

Tooth Caps with Pins

Assortment of long, medium and short Pins

Control Valve Linkage Parts and Cotter Pins

Special Tools

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	10599	1-05.SDT Punch, for 1-05.SD & TT Tooth Caps	1
2	21176	A-176 Spanner wrench for cylinder repair	1

Purging Air From Fuel System Service Procedures Perkins 20 HP and 31.5 HP Diesel Engines

⚠ CAUTION: Review ALL steps before proceeding.

⚠ CAUTION: Always use caution - wear eye protection.

TOOLS NEEDED: WRENCHES - 19mm; 18mm; 13mm


STEPS 1-8

1. Make sure fuel tank has adequate fuel. Make certain fuel filter is full of fuel.
2. Using 19mm wrench loosen bolt on main fuel filter (Fig. A). Ignition switch must be in the ON position to enable fuel to reach upper rails.
3. Operate hand pump using lever (Fig. B) until fuel flows from bolt (Fig. A). If no fuel flows, quickly start and stop engine. Retry hand pump. Repeat if necessary.
4. Tighten bolt (Fig. A).
5. Using 13mm wrench loosen bolt (Fig. C) on top of injector pump. This needs done on all lines on pump.
6. Tighten bolt (Fig. C).
7. Loosen high-pressure line at injector. Using key switch crank engine to purge air from line. Stop cranking. Tighten line when fuel begins to be free of air. This needs done on all lines on pump.
8. Start engine.


⚠ CAUTION: fuel will be under pressure when fuel has a good stream and no air is present.


NOTE: AFTER STEPS 1-8 IF ENGINE DOES NOT START YOU MUST REPEAT STEPS 1-7 UNTIL ALL AIR IS REMOVED FROM SYSTEM BEFORE ENGINE WILL START.

Operator Position for Endloader Use




Operator Position for Backhoe Operation




View of Front Loader Bucket

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	18043	Assembly, ROPS, Front and Rear, T5C/T5D/T6/T7/T9 (Arm Strut Included)	1
2	77075	Light, Flood, Rectangle, T5B/T5C/T5D/T6/T7/T9	4
3	74047	Bulb, Halogen, T5C/T5D/T6/T7/T9	4
4	13306	Bucket, Loader, 60" Wide, T6/T9	1

View of Right Side of Loader Bucket




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	17176	Pin, 5 1/2", Arm Link to Arm Cylinder, T5D/T6/T7/T9	4
2	12037	Rod, Link, Loader Arm, T5D/T6/T7/T9	2
3	13200	Pin, 4 3/4", Front Bucket to Arm, T5C/T5D/T6/T7/T9	4
4	13306	Bucket, Loader, 60" Wide, T6/T9	1
5	13060	Edge, Cutting, 60" Loader, T6/T9	1
6	12048	Arm Link Brace, Right, T5D/T6/T7/T9	2
6	12079	Arm Link Brace, Left, T5D/T6/T7/T9	2
7	17178	Pin, 5 1/2", Arm Link to Arm, T5D/T6/T7/T9	2


View of Underside of Arm Center

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	20063	Fitting, 3/8" MP x 3/8" 90° Swivel, Stubby, T5D/T6/T7/T9	4
2	20176	Fitting, 3/8" M x 3/8" FM, Swivel	8
3	80133	Hose, 3/8" x 26"	2
4	80134	Hose, 3/8" x 28"	2
5	80090	Hose, 3/8" x 18"	2
6	80158	Hose, 3/8" x 38"	2
7	22266	Fitting, 3/8" Tee, Weld-On	4
8	80132	Hose, 3/8" x 70"	4

View of Right Side of Arm Assembly




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	12600	Pin, 5 1/4", Arm Cylinder to Arm, T5C/T5D/T6/T7/T9	2
2	82074	Cylinder, Front Curl, Right, T5D/T6/T7/T9	1
3	82073	Rod, 22 1/4", Front Curl, T5D/T6/T7/T9	2
4	82066	Cylinder, Front Curl, Left, T5D/T6/T7/T9	1
5	12072	Assembly, Arm, T9 2W (Includes Decals)	1
	12073	Assembly, Arm, T9 4W (Includes Decals)	
6	17179	Pin, 5 1/2", Arm Bracket to Arm Cylinder, T5D/T6/T7/T9	2
7	81149	Cylinder, Arm Lift, T6/T9	2
8	12301	Pin, 7 7/8", Arm Cylinder Rod to Frame, T5B/T5C/T5D/T6/T7/T9	1

View of Front Axle 2WD


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	53043	Tie Rod End	4
2	53047	Axle, Front, T6/T9 2WD	1
3	53107	Boss, Spindle Lock, T5D/T6/T9 2WD	2
4	28501	Screw, Set, 1/2" - 20 x 1/2" Plain	4
5	21428	Fitting, Grease 1/4" - 28 Straight	4
6	53050	Spindle, Front, Left, 9 5/8", T5D/T7/T6/T9 2WD	1
7	53137	Hub, 5 on 4.5", T5C/T5D/T6/T7/T9 2WD	2
8	53116	Spindle, Front, Right, 9 5/8", T5D/T7/T6/T9 2WD	1
PIVOT PIN & BOLT			
9	15407	Pin, Front Axle Pivot, T6/T9 2WD	1
10	53081	Nut, Hex, 1 1/4" - 12 Slotted Regular	2
11	15013	Bolt, 1/4" - 20 x 2 1/2" Gr8 Z	2
12	24008	Washer, 1/4" Flat USS	2
13	28504	Nut, 1/4" NC Lock Z	1

View of Front Axle 2WD (continued)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	28503	Nut, Jam, $5/8"$ NF Z	3
2	53054	Tie Rod, T5C/T5D/T6/T7/T9	1
3	53043	End, Tie Rod, w/Kit, T5C/T5D/T6/T7/T9 53221 & 239X0217	4
4	25803	Rod, Power Steering, T5C/T5D/T6/T7/T9 2WD	1
5	25815	Cylinder, Power Steering, T5C/T5D/T6/T7/T9	1
6	23174	Fitting, $1/4"$ M x $1/4"$ F 45° Degrees	2
7	15162	Assembly, Axle, Front, T6/T9 2WD (Completely Assembled) 15162	1

View of Front Axle 2WD - Ball Socket Style (Bumper Not Shown)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	53201	Axle, Front, T7/T9 2W	1
2	81212	Cylinder, Power Steering, Ball Socket Style, T5C/T7/T9 2WD	1
3	24028	Pin, Clevis, $5/8 \times 2 \frac{1}{4}"$	1
4	53160	Pin, Cotter, $1/8 \times 1 \frac{3}{4}"$	1
5	25803	Rod, Power Steering, T5C/T5D/T6/T7/T9 2WD	1

View of Hub Assembly 2WD


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	53116	Spindle, Front, Right, T5D/T7 T6/T9 2WD	1
	53050	Spindle, Front, Left, T5D/T7 T6/T9 2WD	
2	53111	Seal, Front, Hub, T5C/T5D/T6/T7/T9	1
3	53123	Bearing, Front, Inner, T5C/T5D/T6/T7/T9	1
4	53124	Race, 5 on 5.5, Front, Inner, T5C/T5D/T6/T7/T9	1
5	53137	Hub, 5 on 4.5, T5C/T5D/T6/T7/T9	1
6	53058	Race, Old Style, In & Out and New Style Outer, T5C/T5D/T6/T7/T9	1
7	53125	Bearing, Front, Outer, T5C	1
8	53140	Washer, $\frac{3}{4}$ ", SAE Z, Front Axle	1
9	53150	Nut, Castelated, $\frac{3}{4}$ ", Front Hub	1
10	53160	Pin, Cotter, $\frac{1}{8}$ x $1\frac{3}{4}$ "	1
11	53170	Cap, Dust, T3/T4/T5C/T5D/T6/T7/T9	1
12	28506	Nut, Lug, $\frac{1}{2}$ " - 20 ID x $1\frac{3}{16}$ " OD, Front & Rear	5

Four Wheel Drive Front Axle (Bumper Attached)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	53176	Axle, Weldment w/Bumper, Front, T6/T9 4WD	1
2	22021	Bolt, 1/2" - 13 x 3" NC Gr8 Z	2
3	28500	Nut, 1/2" NC Lock Z	2
4	53612	Pin, Pivot, Front Axle, T6/T9 4WD	1
5	62022	Motor, Front Drive Torque, Eaton (NOT SHOWN)	2
6	22174	Fitting - 1/4" MP x 1/4" F 90°, Swivel	2
7	81215	Cylinder, Power Steering, 11 5/8", T6/T9 4WD	1
8	16066	Bumper, Front Axle, T5C/T5D/T6/T7/T9 (Before 10-22-01)	1
	42048	Bumper, Front Axle, T5D/T6/T7/T9 (After 10-22-01)	
9	53043	End, Tie Rod, w/Kit	4



View of 4WD Front Axle



View of 4WD Front Axle



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	53120	Axle/w, 4WD Fr T9, New Cylinder	1
2	53147	Spindle, RH T9 4WD Machintek	1
3	53148	Spindle, LH T9 4WD Machintek	1
Not Shown:			
62033		Drive Motor Key	
53079		4WD Hub	
62032		4WD Shaft Nut	
53022		Lug Studs	


View of Right Front Tire and Rim**View of Right Rear Tire and Rim****View of Right Front Tire and Rim**

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	53170	Cap, Dust, T3/T5C/T5D/T6/T7/T9	1
2	28506	Nut, Lug, 1/2" - 20 ID x 13/16" OD, Front & Rear	5
3	51275	Tire, Front, 23" x 10.5" x 12", T6/T7/T9	1
4	51273	Valve, Tire, Front	1
5	50017	Rim, Front, T5D/T6/T7/T9	1
6	51019	Assembly, Tire & Rim, Front, T6/T7/T9	1

View of Right Rear Tire and Rim


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	51173	Tire, Rear, High Flotation, 31" x 15.5" x 15", T5C/T5D/T6/T7/T9	1
2	50016	Rim, Rear w/guard, 15" x 13", T5C/T5D/T6/T7/T9	1
3	28506	Nut Lug, 1/2" - 20 ID x 13/16" OD, Front & Rear	5
4	55029	Lug Stud, Rear Wheel	5
5	51018	Assembly, Tire & Rim, Rear - HFT, T5C/T5D/T6/T7/T9	1

View of Right Side of Tractor




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	15542	Latch, Hood, T5D/T6/T7/T9	1
2	15127	Hood, T6/T9	1
3	80158	Hose, 3/8" x 38"	1
4	20176	Fitting, 3/8" MP x 3/8" FM Swivel	1
5	12301	Pin, 7 7/8", Arm Cylinder, Rod to Frame, T5B/T5C/T5D/T6/T7/T9	1
6	88999	Wrap, Hose, 3" (Sold per Foot)	4
7	80132	Hose, 3/8" x 70"	4
8	12300	Pin, 6 7/8", Arm to Frame, T5B/T5C/T5D/T6/T7/T9	1


View of Left Side of Tractor



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	12056	Strut, Lift, Arm, Loader, T5C/T5D/T6/T7/T9	1
2	17200	Pin, Quick Release w/Ring Grip, T5C/T5D/T6/T7/T9	1
3	22109	Bolt, 1/2 x 3 1/2" NC Gr8 Z	1
4	17198	Pin, 8 1/2", Arm Lift Cylinder to Strut, T5C/T5D/T6/T7/T9	1


View of Battery from the Left Side of Engine Compartment

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	72038	Cable, Battery to Starter, All Engines, T9	1
2	77022	Battery, Group 26, All Tractors/SCR/Sweeper	1
3	15033	Bracket, Battery Hold Down, T5C/T5D/T6/T7/T9	1
4	72028	Cable, Battery to Ground, Black, T5C/T5D/T6/T7/T9	1


View of Power Steering Gear

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	15106	Gear, Power Steering, T5D/T6/T7/T9	1
2	20033	Fitting, #8 O-Ring x #6 JIC, T5D/T7/T9/Sweeper	2
3	20032	Fitting, #8 O-Ring x #4 JIC FM	2
4	80176	Hose, 1/4" X 65", 1/4 MP x #4 Short JIC 90	2
5	88658	Hose, 3/8" x 58", #6 Short JIC 90 x 38 MP	2

View of Loader Valve Assembly




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	80132	Hose, 3/8" x 70"	4
2	85015	Valve, Front, Drilled and Painted (No Fittings)	1
3	21978	Fitting, 1/2" M 90 x 1/2" FSW	2
4	88880	Hose, 1/2" x 80"	1
5	20786	Fitting, 1/2" MP x 3/8" FSW 90D	4
6	88831	Hose, 1/2 x 31"	1
7	20004	Fitting, 1/2" MP x 1/2" FSW	1
8	20094	Fitting, Reducer, 3/4" x 1/2" FM	1


View of Front Valve Linkage Assembly

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	13947	Link, "L", Front Valve, All Tractors	1
2	13965	Linkage, Ball-Socket, Wobblestick, All Tractors	1
3	13413	Pin, Cotter, 3/32" x 5/8", Linkage, Valve, All Tractors	1
4	25500	Nut, 5/16" - 24 NF Jam	1
5	13944	Block, Pivot, Wobblestick, Front, T5C/T5D/T6/T7/T9	1
6	13411	Link, "U", Valve, All Tractors	1
7	13995	Bolt, Wobblestick Hinge, Front, All Tractors	1

View of Operator Position Facing Dash




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	13140	Cable, Throttle, Diesel, T7/T9	1
2	74000	Switch, Toggle, Double Throw, T5D/T6/T7/T9	1
3	71016	Harness, Wiring, Dash, 55 Amp, Diesel, T6/T9	1
4	77080	Hourmeter, All Tractors	1
5	70335	Switch, Ignition, T6/T9	1
	70111	Switch, Ignition, T6/T9 (after SN 229x0120)	1
6	13942	Knob, Red, Wobblestick Handle, Valve, All Tractors	1
7	13072	Handle, Wobblestick, Front, All Tractors	1
8	13136	Cap, Center, Steering Wheel	1
9	13003	Wheel, Steering, T5C/T5D/T6/T7/T9	1


View of 2WD Transmission Assembly

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	75200	Switch , Alarm, Backup, Electric, T7/T9	2
2	70000	Switch, Neutral, T7/T9	2
3	64003	Motor, Torque, Parker/TRW, T5C/T5D/T6/T7/T9	1
4	66007	Pump, Double Gear, T6/T9 2WD	1
5	64011	Transmission, T6/T9 2WD	1

View of 2WD Sunstrand Transmission Assembly




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	64200	Transmission	1
2	88820	Hose, 1/2" x 20"	2
3	80233	Hose, 1/2" x 80"	1
4	88831	Hose, 1/2" x 31"	1
5	88465	Hose, 1/4" x 65"	1
6	80201	Hose, 1/2" x 57"	1
7	88827	Hose, 3/4" x 27"	1
8	81624	Hose, 1 x 24"	1
9	88658	Hose, 3/8" x 58"	1
10	66007	Pump, Double Gear	1
	80228	Hose Set	


View from Top of Transmission Assembly 4WD

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	13021	Cable, Brake, Long, T6/T9	1
2	60467	Valve, Relief	1
3	13001	Lever, Brake, T6/T9	1
4	64010	Transmission, Tandem Pump, T6 4WD	1
5	13054	Block, Transmission, Pindle, Eaton	1
6	64011	Transmission, T6/T9 2WD	1
7	13020	Cable, Brake, Short, T6/T9	1
8	66007	Pump, Double Gear, T6/T9 2WD	1
	64001	Trans. Seal Kit 4WD	1

View of Cam Roller Center Spring 4WD




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	13034	Bracket, Switch, Neutral Safety, T5D/T6/T7/T9	1
2	20082	Nut, 3/8" NC Flange Z	4
3	13017	Spring, Pedal, T6/T9 4WD	1
4	13009	Block, Cam, T6/T9 4WD	1
5	13010	Plate, Cam, T6/T9 4WD	1
6	13018	Bearing, Pedal Yoke-Cam, T6/T9 4WD	1
7	23008	Nut, 3/8"- 24 NF Lock	1
8	22012	Bolt, 3/8" - 24 x 4" NF Gr8 ZP	1
9	13055	Link, Transmission Control, T6/T9 4WD	1
10	28504	Nut, 1/4" NC Lock Z	2
11	22067	Bolt, 1/4" x 1 1/2" NC Gr8	2
12	13032	Ball Joint, 1/4" - 28 Right Hand Thread	1
13	22078	Nut, Jam, 1/4" - 28 NF Right Hand Thread	1
14	64068	Rod, Linkage Control, T6/T9 4WD	1
15	64002	Transmission, Tandem Pump, T6/T9 4WD	1
16	22079	Nut, Jam, 1/4" - 28 NF Left Hand Thread	1
17	13030	Ball Joint, 1/4" - 28 Left Hand Thread	1


View of T9 2WD Transmission Assembly

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	11128	Spring Assembly	1
2	88820	Hose, 1/2" x 20"	2
3	88827	Hose, 3/4" x 27"	1
4	80201	Hose, 1/2" x 57"	1
5	66007	Gear Pump	1
6	81624	Hose, 1" x 24"	1
7	80250	Hose, 3/8" x 25"	1
8	21032	Filter, In Line Hydraulic	1
9	80233	Hose, 1/2" x 80"	1
10	80251	Hose, 3/8" x 25"	1
11	88659	Hose, 3/8" x 58"	1
12	88831	Hose, 1/2" x 31"	1
13	80232	Hose, 1/2" x 47" Oil Filter to Back Valve (Not Shown)	1
14	80229	Hose, 1/2" x 123" Oil Cooler to Oil Filter (Not Shown)	1
15	80099	Hose, 1/2" x 96" Front Valve to Oil Cooler (Not Shown)	1
16	80230	Hose, 1/4" x 65" Power Steering (Not Shown)	2
	64200	Sauer - Danfoss Transmission	1


View from Right of Foot Pedal Control



ITEM	PART NUMBER	DESCRIPTION	QTY.
2 WHEEL DRIVE			
1	11600	Pedal, Foot	1
2	10139	Bolt, Pedal Stop, T6/T9	2
3	11627	Block, Pillow, Bearing, T5C/T5D/T6/T7/T9	1
4	10140	Bolt, Spring Centering, T6/T9	1
5	13029	Spring, Pedal, Hairpin, T5C/T5D/T6/T7/T9	1
6	11610	Block, Pedal, T5C/T5D/T6/T7/T9	1
7	11620	Shaft, Pedal, T5C/T5D/T6/T7/T9	1
8	16177	Tape, Pedal, Anti-Skid	1
4 WHEEL DRIVE			
9	22008	Bolt, $\frac{3}{8}$ " - 16 x 1" Gr8, Z	1
10	22006	Bolt, $\frac{3}{8}$ " - 16 x $3\frac{1}{4}$ " Gr8, Z, T6/T9	1
11	22016	Bolt, $\frac{3}{8}$ " x $1\frac{1}{2}$ " NC Gr5	2
12	22036	Bolt, $\frac{3}{8}$ " - 16 x $1\frac{1}{4}$ " NC Gr5, Z	4
13	23001	Nut, $\frac{3}{8}$ " - 16 NC Lock Z	2
14	13057	Shaft, Pedal, T6/T9 4WD (Not Shown)	1


View from Right Side of Hydraulic Tank

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	22204	Cap, Hydraulic, w Dipstick & Breather, T5C/T5D/T6/T7/T9 2WD	1

View from Left Side of Fuel Tank


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	11299	Gauge, Fuel, T5D/T6/T7/T9	1
2	15005	Cap, Safety, Green, Diesel, T5C/T5D/T6/T7/T9	1

View of Hydraulic Filter Assembly




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	21030	Filter, Hydraulic	1
2	21029	Head, Filter	1

View from Back of Seat




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	11911	Box, Manual, Operator's Seat	1
2	14260	Assembly, Seat, w/Swivel Disc w/Arm, T5D/T6/T9	1
3	14011	Knob, Seat Shaft, NOT SHOWN	1

View of Operator Position at Rear Valve




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	13073	Handle, Wobblestick, Left Rear, T5C/T5D/T6/T7/T9	1
2	13431	Handle, Outrigger, T5C/T5D/T6/T7/T9	2
3	13123	Handle, Wobblestick, Right Rear, T5C/T5D/T6/T7/T9	1
4	13942	Knob, Red Wobblestick Handle, Valve, T5C/T5D/T6/T7/T9	2
5	15102	Cover, Rear Valve (Boom Latch), T5C/T7/T9	1
6	13135	Cable, Boom Latch Control, T-Handle, T7/T9	1
Not Shown:			
22222		Boom Latch Spring	1
28956		Boom Latch Washer	1


View from Operator Position of Rear Valve (Continued)

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	88425	Hose, $\frac{1}{4}$ " x 25"	1
2	88666	Hose, $\frac{3}{8}$ " x 66"	2
3	88652	Hose, $\frac{3}{8}$ " x 52"	2
4	88688	Hose, $\frac{3}{8}$ " x 88"	1
5	86142	Hose, $\frac{3}{8}$ " x 142"	1
6	88840	Hose, $\frac{1}{2}$ " x 40"	1
7	88857	Hose, $\frac{1}{2}$ " x 57" (2 Wheel Drive)	1
	88845	Hose, $\frac{1}{2}$ " x 45" (4 Wheel Drive)	
8	80075	Hose, $\frac{3}{8}$ " x 125"	1
9	86101	Hose, $\frac{3}{8}$ " x 101"	1
10	80000	Hose, $\frac{3}{8}$ " x 36"	2
11	88420	Hose, $\frac{1}{4}$ " x 20"	1
12	88880	Hose, $\frac{1}{2}$ " x 80"	2

View from Operator Position of Rear Valve (Continued)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	25500	Nut, 5/16" - 24 NF Jam	5
2	13444	Block, Pivot, Universal Rear, T5C/T5D/T6/T7/T9	1
3	21429	Fitting, Grease, 1/4" 90°D	7
4	14052	Plate, Wobblestick & Operator Hazard, T5C/T5D/T6/T7/T9	1
5	13965	Linkage, Ball-Socket, Wobblestick, All Tractors	3
6	13418	Pin, Pivot, Valve Hose Link, T5C/T5D/T6/T7	10
7	13443	Link Bar, Wobblestick Connecting, T5C/T5D/T6/T7/T9	3
8	13411	Link, "U", Valve All Tractors	3
9	13410	Bracket, Aluminum, Rear Valve Handle, T6/T9	2


View from Operator Position of Backhoe Valve (Continued)

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	25718	Fitting, 7/8" MP 90° x 1/2", Swivel	2
2	21765	Fitting, 3/8" MP x 1/4" FP 45° Degrees - Restrictor	2
3	85031	Checks, Anti - Cavitation, T6/T9 (Not Shown)	2
4	21767	Fitting, 3/8" MP x 3/8" MP 45° Degrees - Restrictor	2
5	25286	Fitting, 3/4" MB x 3/8" F - Bushing	12
6	20065	Fitting, #12 O'Ring x 1/2" FPT	2
7	21788	Fitting, 1/2" M x 1/2" FM Swivel 45° Degrees	3
8	21766	Fitting, 3/8" MP x 3/8" FM 45° Degrees	10
9	23413	Restrictor w/Spring (Not Shown)	3

View of Operator Position at Rear Valve (180 Swing)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	13135	Cable, Boom Latch Control, T-Handle, T7/T9	1
2	84046	Wobblestick Pivot Kit Section, Right Rear, V10-1294	1
3	13942	Knob, Red Wobblestick Handle, Valve, T5C/T5D/T6/T7/T9	2
4	85120	Handle, Outrigger/Offset, V10-1294	2
5	84045	Wobblestick Pivot Kit Section, Left Rear, V10-1294	1
6	85120	Handle Outrigger/Offset, r10-1294	1

View of Fitting Location for Rear Valve (180 Swing)


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	20039	Fitting, #10 O-Ring x #8 JIC 90	1
2	20156	Fitting, #8 O-Ring x #6 JIC 90	6
3	20007	Fitting, #10 O-Ring - 7/8MB x 1/2" F, Bushing	1
4	20192	Fitting, 1/2MB x #8 JIC Long 90	1
5	20039	Fitting, #10 O-Ring x #8 JIC 90	1
6	20149	Fitting, #8 MP x #8M JIC Long 90	6

View of Hose Location for Rear Valve (180 Swing)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	80202	Hose, 1/4" x 130"	1
2	80203	Hose, 1/4" x 91"	1
3	80188	Hose, 1/4" x 48"	2
4	80205	Hose, 1/4" x 67"	2
5	80190	Hose, 1/4" x 25"	1
6	80200	Hose, 1/2" x 47"	1
7	80201	Hose, 1/2" x 57"	1
8	80197	Hose, 1/4" x 24"	1
9	80202	Hose, 1/4" x 39"	2
10	80204	Hose, 1/4" x 87"	1
11	80191	Hose, 1/4" x 124"	1
12	80199	Hose, 1/2" x 180"	1

View from Front of Rear Axle (After 1/01/01)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	55045	Axle, Rear, T5C/T5D/T7/T9 2W	1
2	57034	Brake Drum, Weldment	1
3	26288	Bolt, 3/8" x 1 3/4" NF GR8Z	4
4	51800	Flange, Drive Motor, T4/T5C/T5D/T6/T7/T9	1

Top View of Parking Brake Assembly (After 1/01/01)




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	55620	Brake Band	1
2	55606	Brake Cable	1
3	55613	Brake Off Set Link Not Shown - Attaches to Brake Band	1
4	64003	Drive Motor	1
5	51800	Drive Motor Flange Not Shown	1
6	22034	Bolt	1
7	28500	Nut	1
8	23005	Nut	1
9	22038	Bolt	1
10	17028	Bushing, Brake 9/16" ID x 1" OD x 7/8" L	1
	17029	Bushing, Brake 9/16" ID x 1"OD x 1 1/4" L	1
	22042	Bolt, 14mm x 90 mm C2.0z Brake 38748	1
ITEM SHOWN	13197	Spring, Retro Fit Parking Brake	1
ITEM SHOWN	55621	Spring Bracket, Parking Brake	1
	55600	Kit, String Retro Not Shown	1
	57034	Brake Lever & Cable After 1/01/01	1

View from Left Side of Outrigger Assembly



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	81136	Cylinder, Outrigger, T6/T9	1
2	11516	Guard, Outrigger, T6/T9	1
3	11502	Pin, 4 1/8", Outrigger to Cylinder, T5C/T5D/T6/T7/T9	1
4	10202	Pin, Linch (Not Shown)	1
5	11048	Pad, Outrigger Foot	1
6	17156	Pin, 5 1/4", Pull, Outrigger Pad, T5D/T6/T7/T9	1
7	11047	Outrigger, T6/T9	1
8	80126	Hose, 3/8 x 36"	1


View of Left Side of Swing Assembly Non - 180 Degrees



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	15300	Pin, 4 1/8", Swing Cylinder to Swing, T5C/T5D/T6/T7/T9 (Not Shown)	1
2	17035	Pin, 17 1/2", Swing Pin, T6/T9 (Not Shown)	1
3	17208	Pin, 7 3/4", Boom Cylinder to Swing, T5D/T6/T7/T9	1
4	10237	Boom Latch, Curved Boom Non 180%, T5D/T6/T7/T9	1
5	10406	Pin, 8 1/4", Boom to Swing, T6/T9	1
6	21420	Pin, Cotter, Case Hard	1
7	15486	Stop, Swing, T6/T9	1
8	11100	Pin, 6 1/4", Outrigger, Boom, T5C/T5D/T6/T7/T9	1
9	11516	Guard, Outrigger, T6/T9	1
10	17270	Swing Lock Pins	2


INSET - SWING CYLINDER SUB - ASSEMBLY

11	20025	Fitting, 1/4" Tee	2
12	80045	Hose, 1/4" Swing Crossover, 15"	2
13	82070	Cylinder, Swing w/Tee Fitting Non 180%	2
14	20174	Fitting, 1/4" M x 1/4" M Straight, Swivel	2
15	88420	Hose, 1/4" Swing to Valve, 20"	1
16	88425	Hose, 1/4" Swing to Valve, 25"	1



View of Right Side of 180 Degree Swing Assembly

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	81169	Cylinder Trunnion Swing 180D T7/T9	2
2	81168	Rod Swing Cylinder Trunnion T7/T9	2
3	17208	Pin 8 1/4 Boom Cylinder to Swing T7/T9	1
4	10406	Pin 8 1/4 Boom to Swing T7/T9	1
5	17253	Pin 4 3/4 Swing Pivot 180D T7/T9	2
6	17244	Pin 5 1/2 Swing Cylinder T7/T9 180	2
7	13193	Boom Latch Assembly T7/T9	1
8	11100	Pin 6 1/4 Outrigger	4
9	81136	Cylinder Outrigger T9	2
10	11075	Outrigger Assembly T6/T9	2

View of Left Side of Backhoe Assembly





ITEM	PART NUMBER	DESCRIPTION	QTY.
1	81206	Cylinder, Boom and Crowd, T6/T9 Non180	2
2	10706	Pin, 6 5/8", Boom and Dipper, T6/T9	4
3	81131	Cylinder, Rear Curl, T6/T9 after 10/98	1
	20306	Cylinder, Rear Curl, T6/T9 before 10/98	
4	23016	Rod, Rear Curl, T6/T9	1
5	10272	Assembly, Dipper, T9 2W (Includes Decals)	1
5	10273	Assembly, Dipper, T9 4W (Includes Decals)	1
6	10707	Pin, 7 1/4", Boom to Dipper, T6/T9	1
7	10291	Assembly, Boom, T6/T9 (Includes Decals)	1
	10332	180° Boom	1

View of Left Side of 180 Degree Backhoe Assembly**View of Right Side of Rear Bucket & Linkage Assembly**


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	81206	Cylinder Boom & Crowd	2
2	81131	Cylinder R Curl	1
3	10706	Pin 6 5/8" Boom & Crowd T6/T9 R. Curl Cylinder	2
4	10707	Pin, 7 1/4" Boom to Dipper	1
5	10332	Assembly Boom 180° w/Decals	1
6	10336	Assembly Dipper 180° w/Decals	1
7	23016	Rod Rear Curl, T6/T9	1
8	10335	Assembly Dipper 180° w/Decals 2WD	1
9	82137	Rod Boom & Crowd T9 180°	1

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	19095	Bucket, 16", Quick Attach, T6/T9	1
2	22053	Bolt, 1/2" x 3/4" NC Gr8	2
3	28956	Washer, 3/8" SAE	2

View of Left Side of Rear Bucket & Linkage Assembly



Tooth Caps



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	17187	Pin, 8 3/4", Quick Attach Bucket, T6/T9	1
2	28956	Washer, 3/8" SAE	1
3	22008	Bolt, 3/8" - 16 x 1" Gr8 Z	1
4	10812	Pin, 7 5/8", Dipstick to Linkage, T5C/T5D/T6/T7/T9	1
5	20082	Nut, 3/8" NC Flange Z	2
6	19480	Center Assembly, Quick Attach, T6/T9	1
7	17269	Pin, 6 1/2", Rear Curl Cylinder to Quick Attach, T5C/T5D/T6/T7/T9	1
8	17031	Pin, 7 5/8", Linkage to Rear Curl Cylinder, T5C/T5D/T6/T7/T9	1
9	10202	Pin, Linch, T5C/T5D/T6/T7/T9/Sweeper	1
10	17273	Pin, 9", Quick Attach Pull, T6/T9	1
11	18240	Linkage Assembly, Center, T5C/T5D/T6/T7/T9	1
12	17056	Bushing, 1 1/2" ID x 1 3/4"OD x 3" L	1
13	10819	Bushing 1" ID x 1 1/4" OD x 1" L	1
14	17055	Bushing, 1 1/2" ID x 1 3/4" OD x 2" L	1
15	18261	Linkage Link, Right, T5C/T5D/T6/T7/T9	1
16	18260	Linkage Link, Left, T5C/T5D/T6/T7/T9	1



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	10500	Cap, Tooth, Standard Pin, T5C/T5D/T6/T7/T9	NA
2	10590	Cap, Tooth, Tiger	NA
3	10591	Cap, Tooth, Tiger, HD	NA
4	10530	Roll Pin, Tooth Cap, SD	NA

Terramate Suggest Keeping a Current Journal on Replacement Parts for Quick Reference or Field Notes on Your Machine



Remember to Read, Understand and Follow Your Operator's Handbook on Safety and the Correct Procedure for Safe Operation and Handling of Your Compact Tractor Loader Backhoe.



Decal Location - Left Fender



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14070	Decal, Black, W.V., T5C/T5D/T6/T7/T9/Sweeper	1
2	14071	Decal, Diesel Fuel Only, T5C/T5D/T6/T7/T9	1


PART NUMBER	PAINT DESCRIPTION	QTY.
08026	Paint, Yellow, Spray Can Dupont Paint Code #G 9325A	1
08037	Paint, Gray, Spray Can	1

Decal Location - Right Fender




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14308	Decal, Oil, Chevron/Terramate	1
2	14070	Decal, Black, WV	1

Decal Location - Front Arms



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14346	Decal, Yellow, TMC Jumbo Logo	1
2	16181	Kit, Complete, Skid Tape, T5D/T7/T9/T6	2
3	14100	Decal, Pinch Point, T5C/T5D/T6/T7/T9	2



Decal Location - Rear Valve



1 ⚠ OPERATING DANGERS <small>(READ OWNER'S MANUAL BEFORE USING THIS MACHINE)</small> <ul style="list-style-type: none"> 1. KEEP BYSTANDERS AWAY FROM SWING AREA. 2. OPERATE CONTROLS ONLY FROM SEAT. 3. SET ENGINE SPEED TO 1/2 THROTTLE OR LESS. 4. SET ENGINE SPEED TO 1/2 THROTTLE OR LESS. 5. DO NOT DIG UNDER THE MACHINE OR STABILIZERS. 6. WHEN DIGGING ON A HILL, ALWAYS DUMP ON THE UPHILL SIDE. 7. BEWARE OF UNDERGROUND & OVERHEAD UTILITIES. <p style="text-align: center;"> </p> <p style="text-align: center; font-size: small;">PART NO. 1-400-50 © 1989 TERRAMITE CORP.</p>	2 READ OWNER'S MANUAL BEFORE OPERATING	3 1-888-259-0008 <small>HGS Inc. Model No. 1-4000</small>	4 WARNING STAND CLEAR! PINCH POINT! <small>P/N 38186</small>
--	---	--	--

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14284	Decal, Operator Danger T7/T9	1
2	14207	Decal, Read Owners Manual	1
3	14053	Decal, Call Before U Dig	1
4	38186	Decal, Pinch Point, Stand Clear, T7/T9/Sweeper	2



Decal Location - Side View



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14004	Decal, Stand Clear, Red, T5C/T5D/T6/T7/T9	4
2	14021	Decal, Reflector, Amber, T5C/T5D/T6/T7/T9	2
3	14099	Decal, American Flag, T5C/T5D/T6/T7/T9	2
4	14347	Decal, Terramate, Large, T5C/T5D/T6/T7/T9	2
5	14353	Decal, Yellow, Small, T9	2
	14356	Decal, Yellow, Small, T9 4WD	2
6	14070	Decal, Black, W.V., T5C/T5D/T6/T7/T9/Sweeper	2



Decals

Decal Location - Side View (continued)



ITEM	PART NUMBER	DESCRIPTION	QTY.
7	14348	Decal, Yellow, Radius, Terramate, T6/T9	2
8	14054	Decal, Warning, Crush Hazard, T5C/T5D/T6/T7/T9	2
9	14353	Decal, Yellow, Large, T9	2
	14356	Decal, Yellow, Large, T9 4WD	2
10	14004	Decal, Stand Clear Red, T5C/T5D/T6/T7/T9	4
11	14022	Decal, Reflector, Red, T5C/T5D/T6/T7/T9	2
12	143523	Decal, Digging Depth 10', T6/T9	2


Decal Location - Dash



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14201	Decal, Safety First, T5D/G/T6/T7/T9	1
2	14012	Decal, Serial Number Plate, T5D/T7/T9/SCR/Sweeper/Dozer	1
3	14327	Decal, To Raise Hood	1
4	14337	Decal, California Proposition 65 Warning	1
5	14202	Decal, Warning Roll Over, T5D/T6/T7/T9	2
6	14203	Decal, Read Operators Manual, T5C/T6/T7/T9	1
7	14204	Decal, Controls, Front Bucket, T5D/T6/T7/T9	1
8	14220	Decal, Danger, Parking Brake - NIU	1


Decals

Decal Location - Air Filter from Under Hood




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	14510	Decal, Diesel Maintenance Schedule	1

T9 Oil Cooler




HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88100	Return - Oil Cooler	Drive System Distribution Block (A) (SEE PAGE 4.11)
B	88831	Return - Oil Cooler	Front Valve Assembly - Return (A) (SEE PAGE 4.4)


T9 Steering Column 2WD and 4WD

HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88658	"T" Port Steering Column	Drive System Block (B) (SEE PAGE 4.11)
B	88658	"P" Port Steering Column	Transmission - Gear Pump 2WD (D) (SEE PAGE 4.7)
	88658	"P" Port Steering Column	Transmission - Gear Pump 4WD (F) (SEE PAGE 4.8)
C	88465	"L" Port Steering Column	Steering Cylinder (A) (SEE PAGE 4.2)
D	88465	"R" Port Steering Column	Steering Cylinder (B) (SEE PAGE 4.2)


T9 Power Steering Cylinder



HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88465	Steering Cylinder	Steering Column - Port "L" C (SEE PAGE 4.3)
B	88465	Steering Cylinder	Steering Column - Port "R" D (SEE PAGE 4.3)


T9 Loader Valve Assembly

HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88831	Return - Front Valve Assembly	Oil Cooler (B) (SEE PAGE 4.1)
B	88880	Intake - Front Valve Assembly	Rear Valve Assembly - Pressure Port (A) (SEE PAGE 4.13)


T9 4WD Front Axle Assembly

HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88465	Upper Port - Left Motor	Cartridge Block (F) (SEE PAGE 4.10)
B	88465	Lower Port - Left Motor	Cartridge Block (B) (SEE PAGE 4.10)
C	88465	Upper Port - Right Motor	Cartridge Block (E) (SEE PAGE 4.10)
D	88465	Lower Port - Right Motor	Cartridge Block (A) (SEE PAGE 4.10)

T9 Torque Motor - 4WD




HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88181	Torque Motor	Cartridge Block D (SEE PAGE 4.10)
B	88817	Torque Motor	Cartridge Block C (SEE PAGE 4.10)

T9 Transmission - 2WD


HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88614	Discharge Port - Transmission	Oil Tank - Upper return (A) (SEE PAGE 4.14)
B	88820	Exhaust Port - Transmission	Torque Motor - 2WD - (B) (SEE PAGE 4.9)
C	88857	Pressure Port - Gear Pump	Rear Valve Assembly Intake Port (C) (SEE PAGE 4.13)
D	88658	Pressure Port - Gear Pump	Steering Column - Port "P" (B) (SEE PAGE 4.3)
E	88820	Exhaust Port - Transmission	Torque Motor - 2WD - (A) (SEE PAGE 4.9)
F	88820	Charge Intake - Transmission	Oil Tank - Lower Return (C) (SEE PAGE 4.14)
G	81624	Intake Port - Gear Pump	Oil Tank - Intake (D) (SEE PAGE 4.14)

Hydraulics

T9 Transmission - 4WD

HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88614	Discharge Port - Transmission	Oil Tank - Upper Return (A) (SEE PAGE 4.14)
B	80101	Exhaust Port - Transmission	Cartridge Block (H) (SEE PAGE 4.10)
C	80121	Exhaust Port - Transmission	Cartridge Block (I) (SEE PAGE 4.10)
D	88184	Charge Intake - Transmission	Oil Tank - Lower Return (C) (SEE PAGE 4.14)
E	88845	Pressure Port - Gear Pump	Rear Valve Assembly - Intake Port (C) (SEE PAGE 4.13)
F	88658	Pressure Port - Gear Pump	Steering Column (B) (SEE PAGE 4.3)
G	88181	Exhaust Port - Transmission	Cartridge Block (G) (SEE PAGE 4.10)
H	88608	Charge Pump - Transmission	Charge Pump - Transmission
I	88181	Exhaust Port - Transmission	Cartridge Block (J) (SEE PAGE 4.10)
J	81624	Intake Port - Gear Pump	Oil Tank - Intake (D) (SEE PAGE 4.14)


T9 Torque Motor - 2WD




HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88820	Discharge Port - Transmission	Transmission - Exhaust Port - (E) (SEE PAGE 4.7)
B	88820	Torque Motor	Transmission - Exhaust Port - (B) (SEE PAGE 4.7)

T9 4WD Cartridge Block

Prior to 2390201




HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88465	Cartridge Block	Front Axle Assembly (D) (SEE PAGE 4.5)
B	88465	Cartridge Block	Front Axle Assembly (B) (SEE PAGE 4.5)
C	88817	Cartridge Block	Torque Motor (B) (SEE PAGE 4.6)
D	88181	Cartridge Block	Torque Motor (A) (SEE PAGE 4.6)
E	88465	Cartridge Block	Front Axle Assembly (C) (SEE PAGE 4.5)
F	88465	Cartridge Block	Front Axle Assembly (A) (SEE PAGE 4.5)
G	88181	Cartridge Block	Transmission Exhaust Port (G) (SEE PAGE 4.8)
H	80101	Cartridge Block	Transmission Exhaust Port (B) (SEE PAGE 4.8)
I	80121	Cartridge Block	Transmission Exhaust Port (C) (SEE PAGE 4.8)
J	88181	Cartridge Block	Transmission Exhaust Port (I) (SEE PAGE 4.8)

T9 Drive System Distributor Block After 2390201


HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88100	Port A	Oil Cooler - Return Line (A) (SEE PAGE 4.1)
B	88658	Port B	Steering Column - Port "T" (A) (SEE PAGE 4.3)
C	88840	Port C	R. Valve - Return (B) (SEE PAGE 4.13)
D	81012	Port D	Filter - Intake (B) (SEE PAGE 4.12)

T9 Filter Assembly




HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	81028	Filter - Return Line	Oil Tank - Lower Return (B) (SEE PAGE 4.14)
B	81012	Filter - Intake Line	Drive System Block (D) (SEE PAGE 4.11)

T9 Backhoe Valve Assembly




HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88880	Pressure Port - R. Valve Assembly	Front Valve - Intake (B) (SEE PAGE 4.4)
B	88840	Return Port - R. Valve Assembly	Drive System Block (C) (SEE PAGE 4.11)
C	88857	Intake Port - R. Valve Assembly	Transmission Gear Pump 2WD (C) (SEE PAGE 4.7)
	88465	Intake Port - R. Valve Assembly	Transmission Gear Pump 4WD (E) (SEE PAGE 4.8)


T9 Hydraulic Oil Tank Assembly



HOSE	PART NUMBER	STARTING POINT	ENDING POINT
A	88614	Oil Tank - Upper Return	Transmission - Discharge (A) (SEE PAGE 4.7)
B	81028	Oil Tank - Lower Return	Filter Assembly - Return (A) (SEE PAGE 4.12)
C	88820	Oil Tank - Lower Return	Transmission - Charge Intake 2WD (F) (SEE PAGE 4.7)
	88184	Oil Tank - Lower Return	Transmission - Charge Intake 4WD (D) (SEE PAGE 4.8)
D	81624	Oil Tank - Intake	Transmission - Gear Pump Intake 4WD (J) (SEE PAGE 4.8)
	81624	Oil Tank - Intake	Transmission - Gear Pump 2WD (G) (SEE PAGE 4.7)

T9 Pin Chart


Components

T9 Pin Chart 180 Degree Swing

T9 PINS 180			
ITEM	P/N	DESCRIPTION	SIZE
1	13200	FRONT BUCKET/ARMS	1" x 4 3/4"
2	17176	ARM LINK/ARM CYL	1" x 5 1/2"
3	17178	ARM LINK/ARM - TAPPED	1" x 5 1/2"
4	17179	ARM BKT/FRTN CURL	1" x 5 1/2"
5	12600	ARM CYL/ARMS	1" x 5 1/4"
6	12300	ARM/FRAME	1" x 6 7/8"
7	12301	ARM CYL/FRAME - RESALE	1" x 7 7/8"
8	17186	ARM/CYL/FRAME	1" x 8 1/2"
9	10706	RC CYL/DIP & CWD CYL/DIP	1 1/4" x 6 5/8"
10	17031	LINKAGE CURL/CYL	1" x 7 5/8"
11	10206	R.C. CYL/BUCKET Q.D. & BM. LATCH	1" x 6 1/2"
12	17056	R. CURL BUCKET/DETACH	1" x 9 1/2"
13	17187	Q.D. BUCKET T9	1 1/2" x 8 3/4"
14	10812	DIP/LINKAGE	1 1/4" x 7 5/8"
15	10707	BOOM/DIPSTICK	1 1/2" x 7 1/4"
16	17208	BOOM CYL/SWING	1 1/4" x 8 1/4"
17	10406	BOOM/SWING	1 1/2" x 8 1/4"
18	11100	CRD-BM CYL/BM.O.R/FRAME	1" x 6 1/4"
19	11502	OUTRIGGERS	1" x 4 1/8"
20	17156	OUTRIGGER PAD - PULL PIN	1" x 5 1/4"
21	17244	SWING CYL/FRAME	1 1/4" x 5 1/2"
22	17253	SWING T7/T9	1 1/2" x 4 3/4"

T9 Wiring Diagram - Perkins 103-15


Part No. 7-10.1D.T6



T9 WIRING DIAGRAM / 31.5 Hp
P/N 71017

Components


Hydramatic Transmission



***PLEASE PROVIDE SERIAL NUMBER OF MACHINE WHEN ORDERING ANY COMPONENT PARTS.**

Components


Sunstrand Transmission




2001 Starting #239X0206

T9 Glow Plug Timer

P/N 70038
GLOW PLUG TIMER RELAY




Torquemotor Exploded Assembly View

ITEM	DESCRIPTION	ITEM	DESCRIPTION	ITEM	DESCRIPTION
1	Seal	11B	Nut	17	Manifold Plate
2	Retaining Ring	11C	Washer	18	Manifold
3	Back-Up Washer	11D	Bolt	19	Commutator
4	Washer	11E	Lock Washer	20	Seal Ring
5	Seal	12	Bearing	21	Commutator Ring
6	Housing	13	Thrust Bearing	22	Sleeve
7	Seal Ring (2)	14	Drive Link	23	End Cover Assembly
8	Thrust Washer	15	Wear Plate	24	Special Bolt (7)
8A	Thrust Washer	16	Rotor Set	25	Plug
9	Thrust Bearing	16A	Rotor	26	O-Ring
10	Bearing	16B	Vane (7)	27	Spring
11	Coupling Shaft	16C	Stator	28	Valve (Shuttle)
11A	Key				


Components

Gear Pump Part Number 66007




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	64049	Key, Coupler, Cessna	1
2	66030	Kit, Seal, Double Gear Pump	1

Drive Motor Part Number 62000 - 4WD Only



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	62032	Nut, Torque Motor, Front Drive, T6/T9 4WD	2
2	62033	Key, Torque Motor, Front Drive, T6/T9 4WD	2
3	62028	Kit, Seal, Drive Motor, Eaton	1
	53096	Kit, Seal, Drive Motor, Extreme Condition (Optional)	

Components

Rear Axle Assembly

ITEM	PART NUMBER	DESCRIPTION	DANA PART NO.	QTY.
1	55010	Housing-Axle	*	
2	64004	Gear & Pinion Ass'y-Drive	*	
3	55030	Kit-Inner Pinion Bearing	706031X	
4	55040	Shim-Drive Pinion Adjusting Kit	*	
5	55050	Baffle-Pinion Bearing	*	
7	55022	Kit-Outer Pinion Bearing	706030X	
8	55080	Slinger-Pinion Bearing Outer	*	
9	55090	Seal-Pinion	35723	

Continued On Next Page

Rear Axle Assembly (Continued)

ITEM	PART NUMBER	DESCRIPTION	DANA PART NO.	QTY.
11	55110	Washer-Pinion Nut	30186	
12	55120	Nut-Pinion	30185	
13	55130	Companion Flange Assembly	2-1-1881X	
14	55140	Cover-Carrier	*	
15	55150	Gasket-Carrier Cover	34685	
16	55160	Plug-Cover	36472	
17	55170	Bolt-Carrier Cover	34279	
18	55180	Cap-Differential Bearing	**	
19	55190	Bolt-Differential Bearing Cap	500400-20	
20	55200	Kit-Differential Bearing	706032X	
21	55210	Shim-Differential Bearing	*	
22	55220	Case-Differential	*	
23	55230	Bolt-Drive Gear	30187	
24	55240	Pinion-Differential	*	
25	55250	Gear-Differential	*	
26	55260	Thrust Washer-Differential Pinion	*	
27	55270	Thrust Washer-Differential Gear	*	
28	55280	Shaft-Differential	*	
29	55290	Lock-Differential Shaft	13449	
30	55300	Bolt-Break Mounting	34616-1	
31	55310	Nut-Brake Mounting	35704	
32	55320	Seal-Shaft Inboard	34419	
33	55330	Ring-Wheel Bearing Retaining	32755	
34	55340	Bearing Assembly	565903	
35	55350	Seal-Shaft Outboard	35239	
36	55360	Retainer-Oil Seal	35490	
37	55370	Shaft-Axle Flanged	*	
38	55380	Bolt-Wheel	35491	


LIMITED SLIP DIFFERENTIAL ON SER #9975236 & UP


40	55400	Gear-Differential	*	
41	55410	Shaft-Differential	*	
42	55420	Ring-Snap	*	
43	55430	Spacer-Differential Gear (Dished)	*	
44	55440	Plate-Differential	*	
45	55450	Disc-Differential	*	
46	55460	Plate-Differential (Selective Thickness)	*	
47	55470	Clip-Differential Clutch Retainer	*	

Components

General Tightening Torque for Bolts, Nuts and Taperlock Studs

The following charts give the standard torque values for bolts, nuts and taperlock studs for SAE Grade 5 or better quality.

Use these torques for bolts and nuts with standard threads (conversions are approximate).	Thread Size	Standard Torque	
	Inches	Lb. Ft.	N·m*
 standard thread	1/4	9 ± 3	12 ± 4
	5/16	18 ± 5	25 ± 7
	3/8	32 ± 5	45 ± 7
	7/16	50 ± 10	70 ± 15
	1/2	75 ± 10	100 ± 15
	9/16	110 ± 15	150 ± 20
	5/8	150 ± 20	200 ± 25
	3/4	265 ± 35	360 ± 50
	7/8	420 ± 60	570 ± 80
	1	640 ± 80	875 ± 100
	1-1/8	800 ± 100	1100 ± 150
	1-1/4	1000 ± 120	1350 ± 175
	1-3/8	1200 ± 150	1600 ± 200
	1-1/2	1500 ± 200	2000 ± 275
	*1 newton meter (N·m) is approximately the same as 0.1 mkg.		

Metric Fasteners

[Usually, material strength identification on bolt head is with number (i.e., 8.8, 10.9, etc.)]

The chart on the right gives the torque for bolts and nuts with Grade 8.8.


NOTICE: Caution must be taken to avoid mixing metric and standard (customary) fasteners. Mismatched or incorrect fasteners can result in vehicle damage or malfunction, or possible personal injury. Original fasteners removed from the vehicle should be saved for assembly when possible. If new ones are required, caution must be taken to replace with one that is of same part no. and grade or better.

Metric ISO Thread		
Thread Size	Torque	
(mm)	(N·m*)	(Lb. Ft.)
M6	12 ± 4	9 ± 3
M8	25 ± 7	18 ± 5
M10	55 ± 10	40 ± 7
M12	95 ± 15	70 ± 10
M14	150 ± 20	110 ± 15
M16	220 ± 30	160 ± 20
M18	325 ± 50	240 ± 35
M20	450 ± 70	330 ± 50
M22	600 ± 90	440 ± 65
M24	775 ± 100	570 ± 75
M27	1150 ± 150	840 ± 110
M30	1610 ± 200	1175 ± 150
M33	2000 ± 275	1450 ± 200
M36	2700 ± 400	2000 ± 300

ISO - International Standard Organization

*1 newton meter (N·m) is approximately the same as 0.1 mkg.

Schematic-View of Typical Control Valve Assembly



1. Before disassembly, it is suggested that each valve section be marked numerically to avoid incorrect reassembly.
2. Remove three assembly stud nuts from the left end section using a $\frac{9}{16}$ " thin wall socket.
3. Remove valve sections by sliding from assembly studs.

Components


Parts Ordering Information

As of April 1, 1991, the section seals for the V20 changed. The new versions have larger cross section (old was .070, new is .103) and different configurations for open center and closed center sections. The old design utilized the same seals for all versions (two .801 I.D. and two .926 I.D.). The new design uses one configuration for open center (three .924 I.D. and one .799 I.D.) and another configuration

for closed center, load sensing and all outlet covers (two .924 I.D. and two .799 I.D., with one .237 I.D. for load sensing).

The following charts is provided to aid in selection of the proper seals. It is important to note that the seal kits include all O-rings (new and Old), therefore there will be some left unused.

V20 SEAL IDENTIFICATION CHART



The following section seals are included in the Kits:


Standard Kits		Viton Kits	
Old	New	Old	New
(2)6814-002	(2)21867-001	(2)7450-001	(2)9003-117
(2)6815-002	(3)21733-001	(2)7451-001	(3)9002-119
Load sensing kits (additional seals)			
(1)8316-001	(1)21866-001	(1)9002-011	(1)9002-108

Seal kit changes.

K-6121 Section Seal Kit, One Section
 K-6027 Complete Seal Kit, 3 or 4 Way Section
 K-6028 Complete Seal Kit, 4 Way Float Section
 K-6209 Complete Seal Kit, Series 3 or 4 Way Section
 K-6210 Complete Seal Kit, Series 4 Way Float Section
 K-6154 Complete Seal Kit, Load Sensing 4 Way Float
 K-6155 Complete Seal Kit, Load Sensing 3 or 4 Way Section
 K-6156 Section Seal Kit, Load Sensing-One Section
 K-6160 Viton Section Seal Kit, One Section

*Complete Seal Kits include spool seals and O-rings for check plugs.

OLD



6814-002 STD
7450-001 VITON



6815-002 STD
7451-001 VITON



8316-001 STD
9002-011 VITON

NEW



21867-001 STD
9003-117 VITON




21733-001 STD
9002-119 VITON



21866-001 STD
9002-108 VITON

THESE SEALS ARE NOT INTERCHANGEABLE. OLD AND NEW STYLE SECTIONS MAY BE USED IN THE SAME ASSEMBLY PROVIDED THE CORRECT SEALS ARE USED FOR EACH SECTION.

4-Way, 3-Position Valve Section


ITEM NO.	DESCRIPTION	QUANTITY PER SECTION
1	POSITIONER, Spool, Standard	1
2	CHECK, Load	2
3	RETAINER ASSEMBLY, Standard, Includes Screws	1
4	RETAINER, Plate Washer	2
5	WASHER, Back-Up	2
6	SEAL, O-Ring	2
7	HOUSING, Standard	1
8	SPOOL, 4-Way	1

Notes:

1. Seal and washer not sold separately. Order Seal Kit.
2. These are matched parts and are not sold separately.

Buna-N seals are standard for all Gresen valve assemblies. Optional Viton seals are available.


Components

Load Check Plug Assembly

ITEM NO.	DESCRIPTION	QUANTITY PER PLUG ASSEMBLY
	REPLACEMENT LOAD CHECK PLUG ASSEMBLY	
	SEAL KIT, (Contains items 2, 3, 4, 5 and 6)	
1	PLUG, Lift Check, Steel (Heavy Duty)	1
2	SEAL, O-Ring	1
3	WASHER, Back-Up, Outer	1
4	SEAL, O-Ring, Outer	1
5	WASHER, Back-Up, Inner	2
6	SEAL, O-Ring	1
7	POPPET, Lift Check	1
8	SPRING, Lift Check	1


} Not Sold Separately

SPK Monoblock Valve




1. Raise and Lower Control Section
2. Curl and Dump Section

Components

Model J-HP High Pressure Relief


ITEM NO.	DESCRIPTION	QUANTITY PER PLUG ASSEMBLY
1	BALL	1
2	SPRING, Relief (Model SP only)	1
	SPRING, Relief (Models SPK and SSK only)	1
3	GASKET, Relief Body	1
4	O-RING, Adjusting Screw	1
5	O-RING, Valve Seat	1
6	BODY	1
7	SCREW, Adjusting	1
8	NUT, Jam, Adjusting Screw	1
9	NUT, Acorn Cap	1
10	GUIDE, Spring	1
11	WASHER, Spacer (SP)	1
	WASHER, Spacer (SPK)	2
12	POPPET, Check	1
13	SEAT, Valve	1

Hose and Fitting Location for V10 Valve (180 Swing)



Components


View from Operators Position for V10 Valve (180 Swing)




④ Seal Kit - 1 per section, 6 required

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	84046	Kit, Pivot Sect. Wobblestick, RH, V10-1294	1
2	13942	Knob, Red Wobblestick Handle, Valve, T5C/T5D/T6/T7/T9	1
3	84047	Kit, Pivot Sect. Wobblestick, LH v10-1294	1
4	85107	Kit, Section Seal, V10-1294	1
5	84045	Handle Wobblestick L & R	1

Valve Section Service Kits V-10




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85111	Valve Section 1, Work Components V10-1294	1




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85112	Valve Section 2, Work Components V10-1294	1

Components

Valve Section Service Kits V-10




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85113	Valve Section 3&4, Work Components, V10 - 1294	1




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85114	Valve Section 5, Work Components, V10 - 1294	1
2	85116	Kit, Anti - Cavitation Check Cartridge, V10 - 1294	1


Valve Section Service Kits V-10



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85115	Valve Section 6, Work Components, V10 - 1294	1




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85106	Kit, Plug Seal, Relief Cartridge, V10 - 1294	1




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85123	Kit, Plug Seal, Power Beyond, V10 - 1294	1

Components

Valve Section Service Kits V-10


ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85120	Kit, Left, Mechanical Wobblestick Pivot Section, V10-1294	1
2	85121	Kit, Right, Mechanical Wobblestick Pivot Section, V10-1294	1

Valve Section Service Kits V-10




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85119	Screw, Hex Head, V10 - 1294	4
2	85118	Pin, Cotter, V10 - 1294	1
3	85117	Pin, Clevis, V10 - 1294	1
4	85120	Handle, Outrigger/Offset, V10 - 1294	1

Components


Valve Section Service Kits - V10

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85108	Kit, Spool Positioner, V10 - 1294 (See Diagram Below)	1
2	85109	Kit, Load Check Plug, V10 - 1294	1
3	85110	Kit, Spool Lip Seal, V10 - 1294	1



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	85108	Kit, Spool Positioner, V10 - 1294	1

Rod Assembly




	① ROD DIAMETER	② PART NUMBER	③ BEARING BLOCK PART NUMBER	④ PISTON PART NUMBER	SEAL KIT PART NUMBER
Power Steering	1"	25803	22103	21111	21151
Power Steering 4wd	1"	82000	22103	21111	21151
Swing	1"	25201	22103	21111	21151
Arm	1¼"	81148	82058	23110	21525
Front Curl	1⅛"	82073	22203	21111	21125
Rear Curl	1¼"	23016	82058	23110	21525
Outrigger	1¼"	81095	82058	23110	21525
Boom Lift	1½"		82137	81237	Fisher 81196
Crowd	1½"		82137	81237	Fisher 81196


Components


T9 Hydraulic Cylinder Diagram

MODEL T9 LOADER HYDRAULIC CIRCUIT
DUAL CURL CYLINDERS
Hose Lengths (in.)




T9 - Rear Boom Hose Diagram V20




**MODEL T9 BACKHOE HYD CIRCUIT
WOBBLESTICK HOSE DIAGRAM (2WD)**


T9 - 2WD Hydraulic Hose Diagram

PART NUMBER	DESCRIPTION	QTY.
80005	1/4" x 60"	2
88093	1/2" x 93"	1
88831	1/2" x 31"	1
80162	3/8" x 60"	1
80101	1/2" x 10"	1
81624	1" x 24"	1
88614	3/8" x 14"	1
80121	1/2" x 17"	1
80138	1/2" x 20"	1
81028	3/4" x 28"	1
80201	1/2" x 57"	1
80200	1/2" x 47"	1
80031	3/4" x 12"	1
80210	1/2" x 80"	1



Components


T9 - 4WD Hydraulic Hose Diagram

PART NUMBER	DESCRIPTION	QTY.
80216	1/2" x 18"	3
80166	1/4" x 62"	4
88831	1/2" x 31"	1
80162	3/8" x 60"	1
80101	1/2" x 10"	1
81624	1" x 24"	1
88614	3/8" x 14"	1
80121	1/2" x 17"	1
81028	3/4" x 28"	1
80201	1/2" x 57"	1
80200	1/2" x 47"	1
80031	3/4" x 12"	1
80210	1/2" x 80"	1
80217	1/2" x 17"	2
88093	1" x 93"	1
88409	1/4" x 9"	1
80005	1/4" x 60"	2

T7 / T9 SUNSTRAND DIESEL HOSE DIAGRAM WITH OIL COOLER

TRANSMISSION
MUST BE FILLED W/OIL BEFORE
INSTALLING ON MACHINE

CENTER HOSE
20 - DM - TRANS
31 - TANK - TRANS
27 - TANK - TOP FILTER
47 T - R VALVE - BACK FILTER
57 P - R VALVE - TRANS PUMP
80 - R VALVE - LOAD VALVE
123 - FUEL FILTER - OIL COOLER













**Terramate Suggest Keeping a Current Journal on Replacement Parts
for Quick Reference or Field Notes on Your Machine**




Remember to Read, Understand and Follow Your Operator's Hand-book on Safety and the Correct Procedure for Safe Operation and Handling of Your Compact Tractor Loader Backhoe.


Quick Attach Backhoe Buckets




ITEM	PART NUMBER	DESCRIPTION	QTY.
1	19192	Bucket, 8", Quick Attach, T6/T9	1
2	19073	Bucket, 12", Quick Attach, T6/T9	1
3	19095	Bucket, 16", Quick Attach, T6/T9 (Standard)	1
	19172	Bucket, 18", Quick Attach, T6/T9	1
4	19184	Bucket, 20", Quick Attach, T6/T9	1
5	19214	Bucket, 24", Quick Attach, T6/T9	1
6	19148	Bucket, 36", Quick Attach, T6/T9	1
	19157	Bucket, 38", Quick Attach, T6/T9	1
7	19002	Ripper, Quick Attach, T6/T9	1
8	11129	Outrigger Pad Assembly, Flip Over	2
9	19001	Blade, Landscape, Quick Attach, T6/T9	1
10	19434	Edge, Cutting, Bolt-On, 60" w/Bolts, T6/T9	1

View of Clam Shell 4 in 1 Bucket (Factory Installed Only)

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	17138	Pin, Clam & Blade Pivot	2
2	20082	Nut, 3/8" NC Flange Z	6
3	17136	Pin, Clam Cylinder Rod End	2
4	22174	Fitting, 1/4" MP x 1/4" F 90° D, Swivel	2
5	81126	Cylinder, 4 in 1 Bucket	2
6	17137	Pin, Clam Cylinder Head End	2
7	19039	Blade, 4 in 1 Bucket 60"	1
8	19358	Clam, 4 in 1 Bucket 60"	1
9	19502	Bucket Assembly, 4 in 1, Dual, T9 (Complete w/Valve)	1


View of Clam Shell 4 in 1 Bucket from Drivers Position (Factory Installed Option)

ITEM	PART NUMBER	DESCRIPTION	QTY.
1	80119	Hose, 1/4" x 109", MP x MP, Clam Bucket, T6/T9	2
2	23174	Fitting, 1/4" M x 1/4" F 45 D	2
3	20174	Fitting, 1/4" M x 1/4" Straight, Swivel	4
4	88425	Hose, 1/4" x 25", T5C/T5D/T6/T7/T9	2
5	80029	Hose, 1/4" x 42", T5C/T5D/T6/T7/T9	2
6	21403	Handle, Valve, Loader (Used with Clam Shell Bucket Only)	1

**View of Dash for Clam Shell
4 in 1 Bucket
(Factory Installed Option)**

Options

View Under the Dash for Clam Shell 4 in 1 Bucket (Only as Factory Installed Option)



ITEM	PART NUMBER	DESCRIPTION	QTY.
1	80119	Hose, 1/4" x 109", MP x MP, Clam Bucket, T6/T9	2
2	20146	Valve, Loader, 3 Spool (Used with Clam Shell Bucket Only)	1
NOT SHOWN	22784	Fitting, 1/2" M 90 x 1/4" Swivel	2

Translation Chart

ENGLISH	FRANÇAIS	DEUTSCH	ESPAÑOL
adapter	adaptateur	Zwischenstück	adaptador
arm	bras	Arm	brazo
axle assembly	essieu ensemble	Achse vollst	eje conjunto
axle shaft	arbre d'essieu	Achsenwelle	barra eje
bearing	palier	Lager	cojinete
body	carrosserie	Karosserie	carrocería
body assembly	ens carrosserie	Karosserie vollst	conj carrocería
bolt	boulon	Bolzen	bulón
boom	flèche	Hubarm	aguilón
boot	capuchon	Kappe	capuchón
bracket	support	Winkel	grampa
brake head assembly	étrier frein ens	Bremskopf vollst	cabeza freno conj
brake lever assembly	ens levier trein	Bremsebel vollst	conj planca freno
brake shoe	patin frein	Bremsschuh	zapata freno
breather	reniflard	Entlüse	carcasa
bucket	godet	Schaufel	cucharón
bushing	chemise	Buchse	buje
button	bouton	Knopf	botón
cable	câble	Kabel, Seil	Cable
cam	came	Nocke	leva
cap	chapeau	Kappe	tapa
carburetor	carburateur (mélangeur)	Vergaser	carburador
case	carter	Gehäuse	caja
chain	chaînes	Kette	cadena
Channel	canal, moulure	U-Träger, Profil	perfil
choke	enrichisseur	Starterklappe	ahogador
circuit breaker	disjoncteur	Unterbrecher	disyuntor
circuit	circuit	Stromkreis	circuito
clamp	attche, collier	Klammer, Einspannbacke	abrazadera
cleaner	épurateur	Luftreiniger	filtro
clevis	chape	Gabelkopf	horquilla
clip	agrafe	Klemme, Bügel	fbroche
collar	collier	Bundring, Flansch	collar
column	montant, colonne	Säule	columna de dirección
cone	cône, bague intérieure	Konus, Kegel	cónico
connecting	de liaison	verbinden	conectar
connection	connexion	Verbindungsstück,	conexión
connector	raccord	Anschluss, Stecker	conector
control	commande	Steuerung, Betätigung	control
converter	convertisseur	Drehmomentwandler	convertidor
cotter pin	goupille fendu	Splint	chaveta
counterweight	contrepoids	Gegengewicht	contrapeso
coupler	raccord	Anschlussstück, Schnellwechsler	conector, enganche
coupling	accouplement	Verbindungsstück	acoplamiento
cover	couvercle	Deckel	cubierta, tapa
crankcase	carter moteur	Kurbelgehäuse	cárter
crankshaft	vilebrequin	Kurbelwelle	cigüeñal
crosshead	traverse	Kreuzkopf	cruceta
cup	coupelle	Aussenring, Schale	taza

Translation Chart (Continued)

ENGLISH	FRANÇAIS	DEUTSCH	ESPAÑOL
cushion	coussin	Dämpfungselement, Sitzpolster, Vollgummi	amortiguador
cylinder	cylindre	Zylinder	cilindro
cylinder block	bloc-cylindres	Motorblock, Zylinder- block	bloque de motor
decal	décalque, décalcomanie	Abziebild, Beschriftung	calcomania
detachable	amovible	abnehmbar, geteilt	separable
differential	différentiel	Differential	diferencial
diode	diode	Diode	diodo
dipstick	jauge baïonnette	Messstab	varilla medidora
direction switch	inverseur de marche	Richtungsschalter	interruptor de dirección
directional	de sens de marche	richtungsbabhängig	sentido de marcha
disc	disque	Scheibe	disco
distributor	allumeur	Verteiler, Zündverteiler	distribuidor
divider	diviseur, répartiteur	Teller, Verteiler	divisor
dowel	goujon	Passstift, Haltestift	espiga
drive axle	essieu moteur	Antriebsachse	eje motriz
drum	tambour	Trommel	tambor
dual	jamelé, double	doppelt, zweifach	doble
elbow	coude	Kniestück, Winkelstück	codo
element	élément	Element, Einsatz	elemento
enclosure	carter, carénage	Umrandung, Gehäuse	compartimiento
end	terminal, extrémité	Ende	extremo
engine	moteur	Motor	motor
exhaust	échappement	Auspuff	escape
extension	prolongement, rollonge	Verlängerung	extensión
exhaust valve	souparpe d'échappement	Auspuff-, Auslassventil	válvula de escape
fan	ventilateur	Lüfter	ventilador
felt	feutre	Filz	anillo de retén
fender	aile, pare-boue	Schutzblech, Koffflügel	guardabarros
film	film, autocollant	Aufkleber	película
filter	filtre	Filter	filtro
fitting	graisseur, raccord	Nippel, Schraubverbindung	acoplamiento
flap	rabat, bavette	Felgenrand, Klappe	pestaña
flasher	clignotant	Blinkgeber	contacto intermitente
flash lamp	ampoule de clignotant	Blinkleuchte	bombilla intermitente
float	flotteur	gleiten, schwimmen	flotador
floor	sol, plancher	Boden	piso
flow	débit, courant, flux	Strömung, Durchfluss	flujo
flywheel	volant (moteur)	Schwungscheibe	volante
flow protector	protecteur de débit	Durchfluss-Schutzvorrichtung	protector de flujo
foot	pied	Fuss	pie
fork	fourche	Gabel	horquilla
forward	en avant	vorwärts	adelante, hacia adelante
frame	châssis	Rahmen	bastidor
front	avant	vorne, Front	frente, parte delantera
fuel	carburant	Kraftstoff	combustible
FFTL	triple levée	Dreifach-Vollfreihub	alto despejo libre
fuse	fusible	Sicherung	fusible
gasket	joint	Dichtung	junta

Translation Chart (Continued)

ENGLISH	FRANÇAIS	DEUTSCH	ESPAÑOL
guage	jauge	Anzeiger	medidor, indicador, calibrador
gear	pignon, engrenage	Zahnrad, Gang	engranaje
glow plug	bougie de préchauffage	Glühkerze	bujía incandescente
grommet	virole	Tülle, Dichtungsring	arandela aislante
group	ensemble	Gruppe, Satz	grupo
guard	protecteur	Schutz, Abdeckung	protector
guide	guide	Führung	guía
hand brake	frein à main	Handbremse	freno de emergencia
handle	poignée	Griff, Handgriff	asa
harness	faisceau	Kabelbaum, Verdrahtung	mazo de cables
head	tête	Kopf	culata
head lamp	phare AV	Scheinwerfer	luz delantera
height	hauteur	Höhe	altura
hinge	charnière	Gelenk, Scharnier	bisagra
hold down	tendeur	Aufspannvorrichtung	sujetador
holder	support	Halter	soporte
hood	capot	Motorhaube	capó
hook	crochet	Zughaken	gancho
horn	avertisseur	Hupe, Signalhorn	bocina
hose	durite, flexible	Schlauch	manguera
housing	boîtier, carter	Gehäuse	caja
hub	moyeu	Nabe, Radnabe	maza
hydraulic	hydraulique	Hydraulik	hidráulico
ignition	allumage	Zündung	encendido
indicator	indicateur	Anzeigevorrichtung	indicador
injection	injection	Einspritzung	inyección
injector	injecteur	Einspritzventil	inyector
inner	intérieur	innen	interior
insert	pièce rapportée	Einsatz	inserto
instrument	instrument	Instrument	instrumento
insulation	isolation	Isolierung	aislante
insulator	isolateur	Isolator, Nichtleiter	aislador
intake valve	soupape d'admission	Ansaugventil	válvula de admisión, válvula de aspiración
interface	surface de réparation, interface	Übertragungseinheit	entrecara, zona Interfacial
jacket	chemise, jupe	Mantel, Wärmeisolierung	camisa, chaqueta
intermediate	intermédiaire, moyen	indirekt	intermedio, medianero
joint	joint	Gelenk, Verbindung	junta, unión, juntaura
keeper	détente	Gegenmutter, Halter	tirante, fijader, retentór
key	clé, clavette	Schlüssel, Keil	llave
lever	levier	Hebel	palanca
leveler	niveleur, correcteur	Planierer	nivelador
light	lumière	Leuchte	luz
line	canalisation	Leitung	tuberia
liner	chemise, garniture	Laufbuchse	camisa
lining	revêtement, garniture (frein)	Auskleidung, Belag	revestimiento, forro
link	baillette, maillon	Glied, Gelenkstück	eslabón
locknut	contre-écrou	Kontermutter, Siche-	tuerca de traba

Translation Chart (Continued)

ENGLISH	FRANÇAIS	DEUTSCH	ESPAÑOL
lockwasher	rondelle d'arrêt	Federring	arandela de seguridad
magnet	aimant	Magnet	imán
manifold	collecteur	Krümmer	múltiple
master cylinder	maître-cylindre	Hauptzylinder	cilindro maestro
maximum	maximum	maximal	máximo
meter	instrument, mètre	Messgerät	medidor, dosificador
modulating	de modulation	Modulation	modulador
motor	moteur	Motor, elektr.	motor
mount	support	anbauen, montieren	montar
mounting	montage	Befestigung, Anbausatz	montaje
muffler	silencieux d'échappement	Schalldämpfer	silenciador
nipple	graisseur	Schmiernippel	boquilla
nut	écrou	Mutter	tuerca
oil	huile	Öl	aceite
oil level	niveau d'huile	Ölstand	nivel del aceite
outer	extérieur	aussen	exterior
oil filter	filtre à huile	Ölfilter	filtro de aceite
O-ring	joint torique	O-Ring	sello anular
oversize	surdimensionné, majoré	Übermass, Übergrösse	sobre medida
packing	garniture d'étanchéité	Abdichtung	empaqueadura
pad	tampon, coussin	Polster, Unterlagsblock	almohadilla
pan	carter, cuvette	Ölwanne	colector del cárter
panel	tableau	Verkleidungsblech, Instrumentenbrett	panel, tablero de instrumentos
pedal	pédale	Pedal	pedal
pin	goupille, axe	Bolzen, Stift	pasador
pinion	pignon	Ritzel	piñón
piston	piston	Kolben	pistón
pivot	pivot	Anlenk-, Drehpunkt, Auf- hängung	pivote
plate	plaque, plateau	Platte, Blech	placa, plancha
plug	bouchon	Schraubstopfen	tapón, bujía
plunger	plongeur	Tauch-, Ventilkolben	émbolo
polished	poli	poliert	pulido
precleaner	préfiltre	Vorreiniger	antefiltro
primary	priminaire	Haupt-, Vor-, primär	primario
priority	priorité, séquence	Sicherheits-, Vorrang	prioridad
protector	protecteur	Schutzvorrichtung	protector
pulley	pulie	Riemenscheibe	polea
pump	pompe	Pumpe	bomba
push rod	poussoir	Schubstange	varilla de empuje
race	chemin de roulement, cuvette	Lager-, Laufring	anillo de cojinete
radiator	radiateur	Kühlernetz	radiador
rail	rail (glissière)	Schiene	riel, mástil
rear	arrière, AR	rückwärts, hinten	posterior, trasero
rectifier	redresseur	Gleichrichter	rectificador
regulator	régulateur	Regler, Regulievorrichtung	regulador
relay	relais	Relais	réle

Translation Chart (Continued)

ENGLISH	FRANÇAIS	DEUTSCH	ESPAÑOL
relief valve	souape de décharge	Überdruckventil	válvula de alivio
repair	réparation	Reparatur	reparación
required (Reqd.)	requis	erforderlich	requerido
reservoir	réservoir	Tank	depósito, tanque
retainer	arrétoir	Halterung	retén
reverse	marche AR	Rückwärtsgang	marcha atrás, reverso
right hand (RH)	côté droit, à droit	rechts	lado derecho (L.D.)
ring	anneau, joint	Ring	anillo, aro, argolla
rivet	rivet	Niete	remache
rocker arm	culbuteur	Kipphobel	balancín
rod	bielle	Stange, Pleuelstange	varilla
roller	galet	Laufrolle	rodillo
rotor	rotor	Rotor, Laufrad	rotador, rotor, rodete
seal	joint	Dichtring	sello
seal-o-ring	joint torique	O-Ring-Dichtung	anillo, anillo de estancamiento
sealant	produit d'étanchéité	Dichtungsmittel	sellante, sellador
seal-u-cup	joint en demi-lune	U-Profil-Dichtungsring	copa en "U"
seat	siège	Sitz	asiento
secondary	secondaire	Anbau-, Hilfs-, Sekundär	secundario, auxiliar
sender	émetteur, sonde	Geber (Kraftstoffstand)	sensor
sending unit	émetteur	Messwertgeber	unidad sensora
separator	séparateur	Separator, Abscheider	separador
setscrew	vis de fixation	Gewindestift	tornillo de traba, tornillo prisionero
shaft	arbre, axe	Welle	eje, mango largo, rastago
shield	bouclier, écran de protection	Abdeckung, Schild	protector
shim	cale de réglage	Beilagscheibe	calce
short block	bloc-moteur nu	Teil-, Skelettmotor	bloque de motor sin accesoriso, bloque parcial
shroud	panneau, plaque	Abdeckplatte	cubierta, refuerzo de ventilador
sideshift	déport latéral	Seitenschubvorrichtung	desplazador lateral
sleeve	manchon, chemise	Büchse, Hülse	manguito
snap	jonc d'arrêt	Sprengring	anillo de presión, cierre de resorte
socket	douille, chape	Fassung	enchufe
solenoid	solénoïde	Magnetspule	solenoide
spacer	entretoise	Distanzstück	espaciador
spark plug	bougie d'allumage	Zündkerze	bujía
spider	croisillon	Gelenkkreuz	cruceta
spindle	pivot, fusée, broche	Spindel, Achszapfen	punta de eje
spool	tiroir	Ventilstössel	carrete
springs	ressort	Feder	resortes
sprocket	barbotin	Antriebsrad	rueda dentada
standard (Std.)	normal	Standard	estándar
starter	démarreur	Anlasser	arranque
stationary (Stat.)	stationnaire	Aussenmast, stationär	estacionario, inmóvil
stator	stator	Ständer, Stator	estator

Translation Chart (Continued)

ENGLISH	FRANÇAIS	DEUTSCH	ESPAÑOL
steering	directon	Lenkung	dirección
stem	tige	Schaft	vóstago
strainer	filtre, crêpine	Sieb	filtro
strap	sangle	Riemen, Gurt	banda, correa
strut	étai, tirant	Strebe	tirante de dirección
stud	goujon, tenon	Stehbolzen	espárrago
support	support	Auflager, Abstützung	soporte
switch	interrupteur	Schalter	interruptor
tag	étiquette	Anhänger	etiqueta
tapered	conique	konisch, kegelförmig, verjüngt	perfil cónico, aguzado
tappet	poussoir	Anschlag, Stössel	levantaválvulas
tee	té	T-Stück	conexión "T"
terminal	borne	Anschlussklemme	terminal
theristor	thermistor	Thermistor, Temperatur- fühler	termistor
thermostat	thermostat	Thermostat	termostato
tightner	tendeur	Spanner	tensor, ajustador
tilt cylinder	vérin d'inclinaison	Neigezyylinder	cilindro de inclinación
tire	pneumatique	Reifen	neumático
transfer	déclacomanie, autocollant	Abziehbild	transferencia
transmission	transmission, boîte de vi- tesses	Getriebe	transmisión
tread-step	marchepied	Trifffstufe	estribo antirresbalante
tube	tuyau, tube, gicleur	Rohr, Schlauch	tubo
tubing	canalisations	Rohr, Schlauchleitung	tuberías, tubos
undersize	sous-dimensionne, minore	Untermass	bajomedida
union	raccord	Anschlussstück, Verbinaung	unión
universal joint	cardan	Kreuzgelenk	junta universal
upright	montant	senkrecht, Hubgerüst	montante vertical
valve	soupape, clapet	Ventil	válvula
valve mechanism	culbuterie	Ventilsteuerung	mecanismo de válvulas
vacuum	vide, dépression	Vakuum, Unterdruck	vacio, vacuómetro
washer	rondelle	Unterlegscheibe	aradela
water	eau	Wasser	agua
water pump	pompe à eau	Wasserpumpe	bomba de agua
wear strip	bande d'usure	Verschleissstreifen	plancha de desgaste
wheel	roue	Rad	rueda
wheel cylinder	cylindre de roue	Radbremszylinder	cilindro de rueda
wiper	racleur	Wischt, Abstreifer	limpiaparabrisas
wire	fil	Draht, Leitung	alambr, cable
wire harness	faisceau de fils	Kabelbaum	mazo de cables
wire marker	marquer de fil	Kabelmarkierung	marcador de alambre
worm	vis sans fin	Schnecke	tornillo sin fin
wrap	revêtement, enveloppe	Hülle	envolver, envoltura
yoke	chape	Gabelgelenk, Joch	horquilla

A

Adapter Assembly with Power Steering	5.5
Adapter Assembly without Power Steering	5.5
Arm Bucket to Front Curl Pin	5.1, 5.2
Arm Cylinder to Arms Pin	5.1, 5.2
Arm Cylinder to Frame Pin - Resale	5.1, 5.2
Arm Link Brace, Left	2.5
Arm Link Brace, Right	2.5
Arm Link to Arm Cylinder Pin	5.1, 5.2
Arm Link to Arm - Tapped Pin	5.1, 5.2
Arm to Cylinder to Frame Pin	5.1, 5.2
Arm to Frame Pin	5.1, 5.2
Assembly, Arm (2WD, 4WD)	2.7
Assembly, Axle, Front	2.9
Assembly, Boom	2.43, 2.44
Assembly, Dipper	2.43, 2.44
Assembly, ROPS, Front and Rear	2.4
Assembly, Seat, w/Swivel Disc w/Arm	2.30
Assembly, Tire & Rim, Front	2.14
Assembly, Tire & Rim, Rear - HFT	2.14
Axle, Front	2.8, 2.9
Axle, Rear	2.38
Axle/w, 4WD Fr T9, New Cylinder	2.13
Axle, Weldment w/Bumper, Front	2.11

B

Back Up Washer	5.5
Backplate Assy., Cessna, without Power Steering	5.5
Backplate Assy., Eaton, with Power Steering	5.5
Backplate Assy., w/Valve Plate, Eaton	5.5
Baffle-Pinion Bearing	5.12
Ball Joint, 1/4" - 28 Left Hand Thread	2.25
Ball Joint, 1/4" - 28 Right Hand Thread	2.25
Battery, Group 26	2.17
Bearing	5.5
Bearing Assembly	5.13
Bearing Block	5.29
Bearing, Front, Inner	2.10
Bearing, Front, Outer	2.10
Bearing, Pedal Yoke-Cam	2.25
Bearing Race	5.5
Bearing, Thrust	5.5
Bearing, Thrust, F Spin	2.8
Block, Cam	2.25
Block, Pedal	2.27
Block, Pillow, Bearing	2.27
Block, Pivot, Universal Rear	2.33
Block, Pivot, Wobblestick, Front	2.20
Block, Transmission, Pintle, Eaton	2.24
Bolt	2.39
Bolt, 1/2 x 3 1/2" NC Gr8 Z	2.16
Bolt, 1/2" x 3/4" NC Gr8	2.44
Bolt, 1/2" - 13 x 3" NC Gr8 Z	2.11
Bolt, 1/4" - 20 x 2 1/2" Gr8 Z	2.8

Bolt, 1/4" x 1 1/2" NC Gr8	2.25
Bolt, 3/8" x 1 1/2" NC Gr5	2.27
Bolt, 3/8" x 1 3/4" NF GR8Z	2.38
Bolt, 3/8" - 16 x 1" Gr8, Z	2.27, 2.45
Bolt, 3/8" - 16 x 1 1/4" NC Gr5, Z	2.27
Bolt, 3/8" - 16 x 3 1/4" Gr8, Z	2.27
Bolt, 3/8" - 24 x 4" NF Gr8 ZP	2.25
Bolt, 14mm x 90 mm C2.0z Brake 38748	2.39
Bolt, Break Mounting	5.13
Bolt, Carrier Cover	5.13
Bolt, Differential Bearing Cap	5.13
Bolt, Drive Gear	5.13
Bolt, Pedal Stop	2.27
Bolt, Spring Centering	2.27
Bolt, Wheel	5.13
Bolt, Wobblestick Hinge, Front	2.20
Boom, 180°	2.43
Boom Cylinder to Swing PlIn	5.1, 5.2
Boom Latch Assembly	2.42
Boom Latch, Curved Boom	2.41
Boom Latch Spring	2.31
Boom Latch Washer	2.31
Boom to Dipstick Pin	5.1, 5.2
Boom to Swing PlIn	5.1, 5.2
Boss, Spindle Lock	2.8
Box, Manual, Operator's Seat	2.30
Bracket, Aluminum, Rear Valve Handle	2.33
Bracket, Battery Hold Down	2.17
Bracket, Switch, Neutral Safety	2.25
Brake Band	2.39
Brake Cable	2.39
Brake Drum, Weldment	2.38
Brake Off Set Link	2.39
Bucket, 16", Quick Attach	2.44
Bucket, Loader, 60" Wide	2.4, 2.5
Bulb, Halogen	2.4
Bumper, Front Axle	2.11
Bushing, 1" ID x 1 1/4" OD x 1" L	2.45
Bushing, 1 1/2" ID x 1 3/4" OD x 2" L	2.45
Bushing, 1 1/2" ID x 1 3/4" OD x 3" L	2.45
Bushing, Brake 9/16" ID x 1" OD x 7/8" L	2.39
Bushing, Brake 9/16" ID x 1" OD x 1 1/4" L	2.39

C

Cable, Battery to Ground, Black	2.17
Cable, Battery to Starter, Perkins	2.17
Cable, Boom Latch Control, T-Handle	2.31, 2.35
Cable, Brake, Long	2.24
Cable, Brake, Short	2.24
Cable, Throttle, Diesel	2.21
Camplate, For Cessna Transmission	5.5
Camplate, For Eaton Transmission	5.5
Cap Screw	5.5
Cap, Center, Steering Wheel	2.21
Cap, Differential Bearing	
Cap, Dust	2.10, 2.14

INDEX (Continued)

Cap, Hydraulic, w/Dipstick & Breather	2.28
Cap, Safety, Green, Diesel	2.28
Cap, Tooth, Standard Pin	2.45
Cap, Tooth, Tiger	2.45
Cap, Tooth, Tiger, HD	2.45
Case, Differential	5.13
Center Assembly, Quick Attach	2.45
Checks, Anti-Cavitation	2.34
Check Valve Assembly	5.5
Clip, Differential Clutch Retainer	5.13
Companion Flange Assembly 2-1-1	5.13
Coupler	5.5
Cover, Carrier	5.13
Cover Plate	5.5
Cover, Rear Valve (Boom Latch)	2.31
CRD-BM Cylinder to	
Cylinder, Arm Lift	2.7
Cylinder, Boom and Crowd	2.43, 2.44
Cylinder, Front Curl, Left	2.7
Cylinder, Front Curl, Right	2.7
Cylinder, Outrigger	2.40, 2.42
Cylinder, Power Steering	2.9
Cylinder, Power Steering, 11 5/8"	2.11
Cylinder, Power Steering, Ball Socket Style	2.9
Cylinder, Rear Curl	2.43, 2.44
Cylinder, Swing w/Tee Fitting	2.41
Cylinder Trunnion Swing 180D T7/T9	2.42

D

Decal, American Flag	3.5
Decal, Small, Yellow T9	3.5, 3.6
Decal, Small, Yellow, T9 4WD	3.5, 3.6
Decal, Yellow, TMC Jumbo Logo	3.3
Decal, Black, W.V.	3.1, 3.2, 3.5
Decal, California Proposition 65 Warning	3.7
Decal, Call Before U Dig	3.4
Decal, Controls, Front Bucket	3.7
Decal, Danger, Parking Brake - NIU	3.7
Decal, Diesel Fuel Only	3.1
Decal, Diesel Maintenance Schedule	3.8
Decal, Digging Depth 10'	3.6
Decal, Oil, Chevron/Terramite	3.2
Decal, Operator Danger	3.4
Decal, Pinch Point	3.3
Decal, Pinch Point, Stand Clear	3.4
Decal, Radius, Yellow, Terramite	3.6
Decal, Read Owners Manual	3.4, 3.7
Decal, Reflector, Amber	3.5
Decal, Reflector, Red	3.6
Decal, Safety First	3.7
Decal, Serial Number Plate	3.7
Decal, Stand Clear, Red	3.5, 3.6
Decal, To Raise Hood	3.7
Decal, Terramite, Yellow, Large	3.5
Decal, Warning, Crush Hazard	3.6

Decal, Warnning Roll Over	3.7
Dip to Linkage Pin	5.1, 5.2
Disc, Differential	5.13
Drive Motor	2.39
Drive Motor Flange	2.39
Drive Motor Key	2.13
Drive Shaft	5.5

E

Edge, Cutter, 60" Wide	2.5
End, Tie Rod, w/Kit	2.9, 2.11

F

Fitting, 1/2" M 90 x 1/2" FSW	2.19
Fitting, 1/2" M x 3/8" FM 45° Degrees	2.34
Fitting, 1/2" MB x #8 JIC Long 90	2.36
Fitting, 1/2" MP x 1/2" FSW	2.19
Fitting, 1/2" MP x 3/8" FSW 90D	2.19
Fitting, 1/4" Tee	2.41
Fitting, 1/4" MP x 1/4" F 45° Degrees	2.11
Fitting, 1/4" M x 1/4" F 45° Degrees	2.9
Fitting, 1/4" MB x 3/8" F-Bushing	2.34
Fitting, 3/8" MP x 1/4" FP 45° Degrees - Restrictor	2.34
Fitting, 3/8" MP x 3/8" MP 45° Degrees - Restrictor	2.34
Fitting, 3/8" M x 3/8" FM, Swivel	2.6
Fitting, 3/8" MP x 3/8" FM 45° Degrees	2.34
Fitting, 3/8" MP x 3/8" FM Swivel	2.15
Fitting, 3/8" MP x 3/8" 90° Swivel, Stubby	2.6
Fitting, 3/8" Tee, Weld-On	2.6
Fitting, 7/8" MP 90° x 1/2", Swivel	2.34
Fitting, #8 MP x #8 M JIC Long 90	2.36
Fitting, #8 O-Ring x#4 JIC FM	2.18
Fitting, #8 O-Ring x#6 JIC	2.18
Fitting, #8 O-Ring x#6 JIC 90	2.36
Fitting, #10 O-Ring - 7/8 MB x 1/2" F, Bushing	2.36
Fitting, #10 O-Ring x #8 JIC 90	2.36
Fitting, #12 O'Ring x 1/2" FPT	2.34
Fitting, Grease 1/4" - 28 Straight	2.8
Fitting, Grease 1/4" 90° D	2.33
Fitting, Reducer, 3/4" x 1/2" FM	2.19
Flange, Drive Motor	2.38
Front Bucket to Arms Pin	5.1, 5.2

G

Gasket - Carrier Cover	5.13
Gauge, Fuel	2.28
Gear & Pinion Ass'y-Drive	5.12
Gear, Differential	5.13
Gear, Power Steering	2.18
Gear, Pump	2.26
Guard, Outrigger	2.40, 2.41

H

Handle, Outrigger	2.31
Handle, Outrigger/Offset	2.35, 5.27
Handle, Wobblestick, Left Rear	2.31
Handle, Wobblestick, Front	2.21, 5.22
Handle, Wobblestick, Right Rear	2.31, 5.22
Harness, Wiring, Dash, 55 AMP, Diesel	2.21
Hood	2.15
Hose	2.15
Hose, 1/2" x 20	2.26
Hose, 1/2" x 31"	2.19, 2.26
Hose, 1/2" x 40"	2.32
Hose, 1/2" x 45"	2.32
Hose, 1/2" x 47"	2.37
Hose, 1/2" x 57"	2.26, 2.32, 2.37
Hose, 1/2" x 80"	2.19, 2.26, 2.32
Hose, 1/2" x 96"	2.26
Hose, 1/2" x 123"	2.26
Hose, 1/2" x 180"	2.37
Hose, 1/4" Swing to Valve, 20"	2.41
Hose, 1/4" Swing to Valve, 25"	2.41
Hose, 1/4" Swing Crossover, 15"	2.41
Hose, 1/4" x 20"	2.32
Hose, 1/4" x 24"	2.37
Hose, 1/4" x 25"	2.32, 2.37
Hose, 1/4" x 39"	2.37
Hose, 1/2" x 47"	2.26
Hose, 1/4" x 48"	2.37
Hose, 1/4" x 65"	2.26
Hose, 1/4" x 65", 1/4 MP x #4 Short JIC 90	2.18
Hose, 1/4" x 67"	2.37
Hose, 1/4" x 87"	2.37
Hose, 1/4" x 91"	2.37
Hose, 1/4" x 124"	2.37
Hose, 1/4" x 130"	2.37
Hose, 3/4" x 27"	2.26
Hose, 3/8" x 18	2.6
Hose, 3/8" x 25"	2.26
Hose, 3/8" x 26"	2.6
Hose, 3/8" x 28"	2.6
Hose, 3/8" x 36"	2.32, 2.40
Hose, 3/8" x 38"	2.6, 2.15
Hose, 3/8" x 52"	2.32
Hose, 3/8" x 58", #6 Short JIC 90 x 38 MP	2.18, 2.26
Hose, 3/8" x 66"	2.32
Hose, 3/8" x 70"	2.6, 2.15, 2.19
Hose, 3/8" x 88"	2.32
Hose, 3/8" x 101"	2.32
Hose, 3/8" x 125"	2.32
Hose, 3/8" x 142	2.32
Hose, 1" x 24"	2.26
Hourmeter	2.21
Housing Assembly	5.5
Housing-Axle	5.12
Housing, Gasket	5.5

Hub, 4WD	2.13
----------------	------

I

In line Hydraulic Filter	2.26
Inner Race	5.5

K

Key	5.5
Key, Coupler, Cessna	5.10
Key, Seal, Drive Motor, Eaton	5.11
Key, Torque Motor, Front Drive	5.11
Kit-Inner Pinion Bearing	5.12
Kit-Outer Pinion Bearing	5.12
Kit, Anti-Cavitation Check Cartridge, V10-1294	5.24
Kit, Complete, Skid Tape	3.3
Kit, Differential Bearing	5.13
Kit, Left, Mech. Wobblestick Pivot Sec., V10-1294	5.27
Kit, Load Check Plug, V10-1294	5.27
Kit, Right, Mech. Wobblestick Pivot Sec., V10-1294	5.26
Kit, Plug Seal, Power Beyond, V10-1294	5.25
Kit, Plug Seal, Relief Cartridge, V10-1294	5.25
Kit, Seal, Double Gear Pump	5.10
Kit, Seal, Drive Motor, Extreme Condition	5.11
Kit, Section Seal, V10-1294	5.22
Kit, Spool Lip Seal, V10-1294	5.28
Kit, Spool Positioner, V10-1294	5.28
Kit, Pivot Sect. Wobblestick, RH, LH, V10-1294	5.22
Knob, Red, Wobblestick Handle, Valve ...	2.21, 2.30, 2.34, 5.22
Knob, Seat Shaft	2.30

L

Latch, Hood	2.15
Lever, Brake	2.24
Light, Flood, Rectangle	2.4
Link Bar Wobblestick Connecting	2.33
Link, "L", Front Valve	2.20
Link, "U", Valve	2.20, 2.33
Link, Transmission Control	2.25
Linkage Assembly, Center	2.45
Linkage, Ball-Socket, Wobblestick	2.20, 2.33
Linkage Curl to Cylinder Pin	5.1, 5.2
Linkage Link, Left	2.45
Linkage Link, Right	2.45
Lock, Differential Shaft	5.13
Lug Studs	2.13
Lug Stud, Rear Wheel	2.14

M

Motor, Front Drive Torque, Eaton	2.11
--	------

INDEX (Continued)

Motor, Torque, Parker/TRW 2.22

N

Nut	2.39
Nut, 1/2" NC Lock Z	2.11
Nut, 1/4" NC Lock Z	2.8, 2.25
Nut, 3/8" NC Flange Z	2.25, 2.45
Nut, 3/8" - 16 NC Lock Z	2.27
Nut, 3/8" - 24 NF Lock	2.25
Nut, 5/16" - 24 NF Jam	2.20, 2.33
Nut, Brake Mounting	5.13
Nut, Castelated, 3/4", Front Hub	2.10
Nut, Hex, 1 1/4" - 12 Slotted Regular	2.8
Nut, Jam, 1/4" - 28 NF Left Hand Thread	2.25
Nut, Jam, 1/4" - 28 NF Right Hand Thread	2.25
Nut, Jam, 5/8" NF Z	2.9
Nut, Lug, 1/2" - 20 ID x 13/16" OD	2.10, 2.14
Nut, Pinion	5.13
Nut, Torque Motor, Front Drive	5.11

O

O-Ring, 1/16" x 3/8"	5.5
O-Ring, 1/16" x 7/16"	5.5
O-Ring, 1/16" x 3 1/4"	5.5
O-Ring, 3 3/32" x 7/8"	5.5
O-Ring, 3 3/32" x 41/64"	5.5
O-Ring, 3/32" x 15/16", Outer Pintle	5.5
O-Ring, Molded	5.5
O-Ring, Outer Pintle	5.5
Outrigger	2.40
Outrigger Assembly	2.42
Outrigger Pin	5.1, 5.2
Outrigger Pad - Pull Pin	5.1, 5.2

P

Pad, Outrigger Foot	2.40
Paint, Gray, Spray Can	3.1
Paint, Yellow, Spray Can	3.1
Pedal, Foot	2.27
Pin	5.5
Pin, 4 1/8", Outrigger to Cylinder	2.40
Pin, 4 1/8", Swing Cylinder to Swing	2.41
Pin, 4 3/4", Front Bucket to Arm	2.5
Pin, 4 3/4", Swing Pivot 180D	2.42
Pin, 5 1/2", Arm Bracket to Arm Cylinder	2.7
Pin, 5 1/2", Arm Link to Arm	2.5
Pin, 5 1/2", Arm Link to Arm Cylinder	2.5
Pin, 5 1/2", Swing Cylinder 180	2.42
Pin, 5 1/4", Arm Cylinder to Arm	2.7
Pin, 5 1/4", Pull, Outrigger Pad	2.40
Pin, 6 1/2", Rear Curl Cylinder to Quick Attach	2.45
Pin, 6 1/4", Outrigger	2.42
Pin, 6 1/4", Outrigger, Boom	2.41

Pin, 6 5/8", Boom & Crowd R. Curl Cylinder	2.44
Pin, 6 5/8", Boom and Dipper	2.43, 2.44
Pin, 6 7/8, Arm to Frame	2.15
Pin, 7 1/4", Boom to Dipper	2.43
Pin, 7 3/4", Boom Cylinder to Swing	2.41
Pin, 7 5/8", Dipstick to Linkage	2.45
Pin, 7 7/8" Arm Cylinder, Rod to Frame	2.7, 2.15
Pin, 7 5/8", Linkage to Rear Curl Cylinder	2.45
Pin, 8 1/2", Arm Lift Cylinder to Strut	2.16
Pin, 8 1/4", Boom to Cylinder to Swing	2.42
Pin, 8 1/4", Boom to Swing	2.41, 2.42
Pin, 8 3/4", Quick Attach Bucket	2.45
Pin, 9", Quick Attach Pull	2.45
Pin, 17 1/2", Swing Pin	2.41
Pin, Clevis , 5/8 x 2 1/4"	2.9
Pin, Cotter, 1/8 x 1 3/4"	2.9, 2.10
Pin, Cotter, 3/32" x 5/8", Linkage, Valve	2.20
Pin, Cotter, Case Hard	2.41
Pin, Cotter, V10-1294	5.27
Pin, Clevis, V10-1294	5.27
Pin, Front Axle Pivot	2.8
Pin, Linch	2.40, 2.45
Pin, Quick Release w/Ring Grip	2.16
Pin, Pivot, Front Axle	2.11
Pin, Pivot, Valve Hose Link	2.33
Pinion, Differential Shaft	5.13
Piston	5.29
Plate, Cam	2.25
Plate, Differential	5.13
Plate, Differential (Selective Thickness)	5.13
Plate, Valve	5.5
Plate, Wobblestick & Operator Hazard	2.33
Plug Assembly	5.5
Poppet Filter Relief	5.5
Plug, Cover	5.13
Pump, Double Gear	2.22, 2.24
Punch, for 1-05.SD & TT Tooth Caps	2.2

Q

Q.D. Bucket T9 Pin	5.1, 5.2
--------------------------	----------

R

R. Curl Bucket to Detach Pin	5.1, 5.2
Race, Old Style, In & Out and New Style Outer	2.10
RC Cylinder to Bucket Q. D. & BM. Latch Pin	5.1, 5.2
RC Cylinder to Dip & CWD Cylinder to Dip Pin	5.1, 5.2
Restrictor w/Spring	2.34
Retainer, Oil Seal	5.13
Retaining Ring	5.5
Rim, Front	2.14
Ring, Snap	5.13
Ring, Wheel Bearing Retaining	5.13
Rod	5.29

Rod, 22 1/4", Front Curl	2.7
Rod Boom & Crowd 180°	2.43
Rod, Link, Loader Arm	2.5
Rod, Linkage Control	2.25
Rod, Power Steering	2.9
Rod, Rear Curl	2.43, 2.44
Rod Swing Cylinder Trunnion	2.42
Roll Pin, Tooth Cap, SD	2.45
Rotating Kit Assembly	5.5
Rotating Rebuild Kit, Cessna	5.5

S

Sauer - Danfoss Transmission	2.26
Screw, Set, 1/2" - 20 x 1/2" Plain	2.8
Screw, Hex Head, V10-1294	5.28
Screw, Trunnion Cover	5.5
Seal Cover	5.5
Seal Kit	5.30
Seal Repair Kit, Cessna	5.5
Seal Repair Kit, Eaton	5.5
Seal, Front, Hub	2.10
Seal, Pinion	5.12
Seal, Pintle	5.5
Seal, Shaft Inboard	5.13
Seal, Shaft Outboard	5.13
Separator Plug	5.5
Shaft, Axle Flanged	5.13
Shaft, Differential	5.13
Shaft Nut, 4WD	2.13
Shaft, Pedal	2.27
Shaft Seal	5.5
Shim-Differential Bearing	5.13
Shim-Drive Pinion Adjusting	5.12
Shim-Pinion Bearing Adjusting	5.12
Sleeve Cover	5.5
Slinger-Pinion Bearing Outer	5.12
Spacer, Differential Gear (Dished)	5.13
Spanner Wrench for Cylinder Repair	2.2
Spindle, Front, Left	2.10
Spindle, Front, Right	2.10
Spindle, Front, Right, 9 5/8"	2.8
Spindle, LH T9 4WD Machintek	2.13
Spindle, RH T9 4WD Machintek	2.13
Spreader	5.5
Spring	5.5
Spring Assembly	2.26
Spring Bracket, Parking Brake	2.39
Spring Pedal	2.25
Spring Pedal, Hairpin	2.27
Spring Retainer	5.5
Spring, Retro Fit Parking Brake	2.39
Steel Ball	5.5
Stop, Swing	2.41
Strut, Lift, Arm, Loader	2.16
Swing T9 Pin	5.1, 5.2

Swing Cylinder to Frame Pin	5.1, 5.2
Swing Cylinder to Swing Pin	5.1
Swing Lock Pins	2.41
Switch, Alarm, Backup, Electric	2.22
Switch, Ignition	2.21
Switch, Neutral	2.22
Switch, Toggle, Double Throw	2.21

T

Tape, Pedal, Anti-Skid	2.27
Thrust Washer, Differential Gear	5.13
Thrust Washer, Differential Pinion	5.13
Tie Rod	2.9
Tire, Front, 23" x 10.5" x 12	2.14
Tire, Rear w/guard, 15" x 13"	2.14
Transmission	2.22, 2.24
Transmission, Seal Kit 4WD	2.24
Transmission, Tandem Pump	2.24, 2.25
Torquemotor Exploded Assembly	5.9
Trunnion Cover	5.5

V

Valve, Front, Drilled and Painted	2.19
Valve, Relief	2.24
Valve Section 1, Work Components V10-1294	5.23
Valve Section 2, Work Components V10-1294	5.23
Valve Section 3, Work Components, V10-1294	5.24
Valve Section 4, Work Components, V10-1294	5.24
Valve Section 5, Work Components, V10-1294	5.24
Valve Section 6, Work Components, V10-1294	5.25
Valve, Tire, Front	2.14

W

Washer	5.5
Washer, 1/4" Flat USS	2.8
Washer, 3/4", SAE Z, Front Axle	2.10
Washer, 3/8" SAE	2.44
Washer, Pinion Nut	5.13
Wheel, Steering	2.21
Wobblestick Pivot Kit Section, Left Rear	2.35
Wobblestick Pivot Kit Section, Right Rear	2.35
Wrap, Hose, 3"	2.15

SAMPLE Limited New Product Warranty

WE WARRANTY TO THE ORIGINAL CONSUMER/PURCHASER THAT EACH NEW PRODUCT SOLD BY US WILL BE FREE FROM MANUFACTURING DEFECTS IN NORMAL SERVICE USE FOR A PERIOD OF ONE (1) YEAR FROM DATE OF PURCHASE.

Our obligation under this warranty is expressly limited, solely at our option, to the replacement or repair at the premises of Terramite Corporation, 600 Goff Mountain Road, Charleston, West Virginia 25356, or at a service facility designated by us, of such part or parts as inspection shall disclose to have been defective. This warranty does not apply to defects caused by casualty or unreasonable use (including faulty repairs by others and failure to provide reasonable and necessary maintenance) nor to ordinary wear and tear, while in the possession of the consumer/purchaser.

This warranty is for replacement or repair of defective parts only, and does not provide for replacement of complete products due to a defective part or parts nor does it cover any charges of whatever kind in connection with the replacement of any such defective parts.

We shall not be responsible for special, indirect, incidental or consequential damages of any kind including, but not limited to, labor costs or transportation charges in

connection with the replacement or repair of defective parts.

Components such as engines, pumps and batteries which are supplied by other manufacturers, are warranted by the manufacturer's nearest "Factory Service Center" for repair or replacement of those items. However, when necessary, the manufacturer will act as your agent to secure adjustment.

To obtain warranty service, purchaser must bring the product to an authorized Terramite Service facility. For the facility nearest you, contact Terramite Corporation, P.O. Box 7146, Charleston, WV 25356 or telephone (304) 776-4231.

This warranty gives you specific rights and you may have other rights which vary from state to state. This warranty is in lieu of any other warranty, whether written, verbal, expressed or implied and may not be modified or changed by Terramite Distributors or Dealers. This warranty shall be null and void unless the section below has been filled in and the manufacturer's copy of this document is returned to Terramite Corporation, P.O. Box 7146, Charleston, WV 25356 within ten (10) days of the date of purchase by the original owner.

MODEL# _____ SERIAL# _____ ENGINE# _____

PURCHASED FROM _____ CERTIFICATE OF ORIGIN# _____

NAME OF PURCHASER _____

ADDRESS _____

PHONE (_____) _____ CERTIFICATE OF ORIGIN# _____

TYPE OF BUSINESS _____

IS THIS YOUR FIRST TERRAMITE? _____

WHAT KIND OF SIMILAR EQUIPMENT DO YOU OWN? _____

OPTIONS _____

DATE OF PURCHASE _____ SIGNATURE _____

(ORIGINAL PURCHASER)

**Fill in the information requested above.
This will be useful anytime you need to order parts.**

**This is only a SAMPLE of the Limited New Product Warranty
provided with each new machine to the original owner.**